


Service Manual

Digital Disk Recorder WJ-HD500



SPECIFICATIONS

General

Power Source :	220-240 V AC, 50 Hz
Power Consumption :	55 W
Ambient Operating Temperature :	+5°C - +45°C (41°F - 113°F)
Ambient Operating Humidity :	Less than 85 %
Dimensions :	420 mm (W) × 88 mm (H) × 360 mm (D) [16 0/16" (W) × 3 7/16" (H) × 13 3/4" (D)]
Weight :	8 kg (17.6 lbs.)

Input and Output

Video Input :	1.0 V _{p-p} /75 Ω Composite video signal with 75 Ω Automatic Termination / Looping through (x16)
Video Output :	1.0 V _{p-p} /75 Ω Composite video signal Looping through (x16)
Spot Output :	1.0 V _{p-p} /75 Ω Composite video signal (x1)
Multiscreen Output :	1.0 V _{p-p} /75 Ω Composite video signal (x1)
Audio Input :	-10 dB unbalanced, RCA standard jack
Audio Output :	-10 dB unbalanced, RCA standard jack
Extension Storage Port :	SCSI Interface 50-pin Half Pitch D-sub connector (x1)
Copy Port :	SCSI Interface 50-pin Half Pitch D-sub connector (x1)
Control Port :	25-pin Full Pitch D-sub connector (x1)
Alarm Port :	25-pin Full Pitch D-sub connector (x1)
Data Port :	RS-485 6-conductor modular jack (RJ-11)
Remote Port :	For Exclusive Remote Controller, serial interface (RJ-11)
Serial Port :	RS-232C 9-pin Full Pitch D-sub connector
10/100BASE-T Port :	10Base-T and 100Base-TX, 8-conductor modular jack (RJ-45) (Installed Optional Network Board)

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

Panasonic

© 2001 Matsushita Communication Industrial Co., Ltd.
All rights reserved. Unauthorized copying and distribution is a violation of law.

CONTENTS

Major Operating Controls and Their Functions	1
DIP Switch Setting of SCSI-IDE Board	5
Adjustment Procedure	5
Location of Test Points and Adjusting Controls	11
wiring Diagram	12
Block Diagram	13
Analog Board	13
Front Board	14
Main Board (1/10)	15
Main Board (2/10)	16
Main Board (3/10)	17
Main Board (4/10)/(5/10)	18
Main Board (6/10)/Rear Board	19
Main Board (7/10)	20
Main Board (8/10)/(9/10)	21
Main Board (8/10)/(10/10)	22
Motion Detector Board	23
Schematic Diagram	25
Analog Board	25
Rear Board	26
Motion Detector Board (1/2)	28
Motion Detector Board (2/2)	29
Main Board (1/10)	31
Main Board (2/10)	32
Main Board (3/10)	33
Main Board (4/10)	34
Main Board (5/10)	35
Main Board (6/10)	36
Main Board (7/10)	37
Main Board (8/10)	38
Main Board (9/10)	39
Main Board (10/10)	40
Front Board/LED Board	43
Power Board	44

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public.
It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product.
Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.



This symbol warns the user that uninsulated voltage within the unit may have sufficient magnitude to cause electric shock. Therefore, it is dangerous to make any kind of contact with any insulate part of this unit.



This symbol alerts the user that important literature concerning the operation and maintenance of this has been included. Therefore, it should be read carefully in order to avoid any problems.

IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are indicated by the "△" mark on the schematic diagram and the replacement parts list. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent X-radiation, shock, fire, or other hazards. Do not modify the original design without permission of manufacture.

Warning

The lithium battery in this equipment must only be replaced by qualified personnel. When necessary, contact your local Panasonic supplier.

CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the equipment manufacturer. Discard used batteries according to manufacturer's instructions.

STANDARD ACCESSORIES


AC Power Cord	2 pcs.
Rack Mounting Bracket	2 pcs.
Screw for Rack Mounting Bracket (M4x10)	4 pcs.
Absorber	4 pcs.
Sleeve	4 pcs.
Earth Lug	1 pc.
Hard Disk Fixing Screw	4 pcs.

Conductor View

Analog Board	24
Rear Board	27
Motion Detector Board	30
Main Board	41
Front Board/LED Board	42
Power Board	45
Exploded View	46
Replacement Parts List	47

MAJOR OPERATING CONTROLS AND THEIR FUNCTIONS

■ Front View



- 1 Operate Indicator (OPERATE)**
This indicator is on when the power of the WJ-HD500 Digital Disk Recorder is turned on.
- 2 Timer Indicator (TIMER)**
Lights to indicate when the TIMER is set to INT (internal timer) in the setup menu.
- 3 Remote Indicator (REMOTE)**
Lights to indicate when the Disk Recorder is controlled by an outboard device via the Serial or 10/100BASE-T port on the rear of the Disk Recorder.
- 4 Alarm Suspend Indicator (ALARM SUSPEND)**
Lights to indicate that the alarm suspension mode is selected.
- 5 Alarm Reset Button (ALARM RESET)**
This button cancels an activated alarm. Pressing this button will reset the alarm and return the system to the condition before the alarm function was activated.
- 6 Alarm Indicator (ALARM)**
This indicator blinks to indicate that an alarm condition exists. It changes to a steady light when the alarm is reset automatically. To turn the indicator off, press the ALARM RESET button.
- 7 Sequence Button (SEQUENCE)**
Runs the assigned sequence on the selected monitor screen for the specified duration. During the sequence, pressing this button will pause the sequence that is being run on the monitor screen.


- The LED indicates the status as follows.
On: Sequence is being run.
Blinking: Sequence is in pause mode.
- 8 Multiscreen Selection Button (MULTISCREEN SELECT)**
Selects the multiscreen pattern to be displayed on the Multiscreen Monitor that is connected to the MULTISCREEN OUT on the rear of the Recorder. Pressing this button will toggle the display on the monitor screen as shown below.
4 → 7 → 9 → 10 → 13 → 16 → 4 screen segments
- 9 Monitor Selection Button (SPOT / MULTISCREEN)**
Selects to control the display on the screen for either the Spot or Multiscreen Monitor. Pressing this button will toggle the indicator in the button on and off to indicate the selected monitor as shown below.
On: Indicates the Spot monitor is selected.
Off: Indicates the Multiscreen monitor is selected.
- 10 Lock Button (LOCK)**
Toggles to enable or disable the button lock function on both front panels of the Disk Recorder and Remote Controller. The LED indicates the status as shown below.
On: The button lock is enabled.
Off: The button lock is disabled.
While On, the button lock will be released only if the pre-set password is entered in the password inquiry window.

- 11 Numeric Buttons (1 - 16)**
These buttons are used for numeric input into the system such as the video selection, password, etc. The indicator in the button lights up to indicate as shown below.
Green: The input is displayed on the monitor.
Yellow: The input is displayed on the monitor and recorded on the Hard Disk.
Orange: The input is recorded on the Hard Disk (no display).
- 12 Set Button (SET)**
During the setup, this button is used to display a submenu in the setup menu if the item has its own setting menu.
- 13 Increment / Decrement Button (I, D)**
These buttons are used to zoom in and out the zoomed image presently displayed on the Multiscreen Monitor. During the setup, these buttons are used to select the item parameter in the setup menu.
- 14 Recording Stop Button (REC STOP)**
Pressing this button will stop the recording.
- 15 Recording Preview Button (REC PREVIEW)**
Use this button to display the playback image with the live images on the Multiscreen Monitor. The LED indicates the status as shown below.
On: The selected playback image is displayed.
Blinking: Prompts you to select the numeric button for displaying the playback image.
- 16 Index Button (INDEX)**
Displays the all record list (list and thumbnail) or alarm and emergency list depending on the status of the ALARM SEARCH button.
- 17 Group Selection Button (GROUP SELECT)**
Selects the camera group from among group 1, 2, 3 and 4. The LED will light while any of the groups is selected.
- 18 Stop Button (STOP)**
Pressing this button will stop the playback.
- 19 Playback / Pause Button (PLAY/PAUSE)**
Pressing this button will start the playback. During playback, pressing this button will pause the playback. The indicator in the button lights to indicate as shown below.
On: Indicates that the playback mode is selected.
Blinking: Indicates that the pause mode is selected.

- 20 Record Button (REC)**
Pressing this button will start the recording manually when the Timer parameter is set to OFF in the setup menu. The indicator in the button lights up to indicate that the recording mode is selected.
- 21 JogDial**
Rotate in paused playback to move forward or backward to the next recorded image. It is also used to select the recording number when the recorded list is displayed on the monitor.
- 22 Shuttle Ring**
Rotate in playback or paused playback to search the recorded images forward or backward at variable speed.
- 23 Display Button (DISPLAY)**
Pressing this button will display the recording list with the search editing area to find the record to be played back.
- 24 Alarm Search Button (ALARM SEARCH)**
Selects either the list of alarm and emergency recordings or all recordings to be displayed on the Multiscreen Monitor. The LED indicates the status of selection as shown below.
On: Search records for alarm and emergency recordings.
Off: Search records for all recordings.
- 25 Electronic Zoom Button (EL-ZOOM)**
This button is used to zoom an image presently displayed in a single spot on the Multiscreen Monitor.
- 26 Summer Time Button (SUMMER TIME)**
The SUMMER TIME button is recessed inside the front panel opening. Pressing this button will shift the internal clock to the summer time or vice versa.
- 27 Copy Button (COPY)**
Copies the selected images on to the DVD-RAM disk when the system is equipped the DVD-RAM Drive unit.
- 28 Setup / Escape Button (SETUP/ESC)**
This button is used in the Disk Recorder's Setup operation. Pressing this button for two seconds or more will open the Disk Recorder's Setup menu on the screen of the Multiscreen Monitor. During the setup, press this button to return to the previous setup menu.

- 29 Direction Buttons (V, A, L, R)**
These buttons are used to select an area for a zoomed image displayed on the Multiscreen Monitor. During the setup, these buttons are used to move the cursor position in the setup menu of the Disk Recorder.
▼: Downward
▲: Upward
◀: Left
▶: Right

■ Rear View




- 31 Multiscreen Output Connector (MULTISCREEN OUT)**
The video output signal for the Multiscreen Monitor is provided via this connector. It can be displayed as the video input in a multiscreen mode (4, 7, 9, 10, 13, 16 screen segments). It also displays the Recorder's playback images. Pressing the SETUP/ESC button for two seconds or more will automatically select the Multiscreen Monitor and display the Disk Recorder's Setup menu.
- 32 Spot Output Connector (SPOT OUT)**
The video output signal for the Spot Monitor is provided via this connector. Displaying the Disk Recorder's playback is disabled.
- 33 Audio Input Connector (AUDIO IN)**
For audio input from an external device, if applicable.
- 34 Audio Output Connector (AUDIO OUT)**
For audio output to an external device, if applicable.
- 35 Extension Storage Port (EXT STORAGE)**
For connecting the optional Extension Unit.
- 36 Control Port (CONTROL)**
The port has the functions listed below. Make connections to these pins as needed for operating your system.

The pin assignment of the port is shown below.

Pin No.	Designation	Pin No.	Designation
1	Group Recording Output	14	Disk Recorder Error Output
2	Manual Recording Output	15	Ground
3	Emergency Recording Output	16	Ground
4	Sequence Timing Output	17	Power Failure Detect Input
5	DVD Remain Space Output	18	Power Failure Proceeding Output
6	HDD Remain Space Output	19	Power Failure Process Completion Output
7	Thermal Error Input (Extension 1)	20	Ground
8	Thermal Error Input (Extension 2)	21	Emergency Recording Input
9	Thermal Error Input (Extension 3)	22	Time Adjustment Output
10	Thermal Error Input (Extension 4)	23	Daylight Savings Select
11	Thermal Error Input (Extension 5)	24	Time Adjustment Input
12	Thermal Error Input (Extension 6)	25	Ground
13	Thermal Error Input (DVD Unit)		

- 47 Alarm Port (ALARM)**
This port accepts the alarm input from the associated alarm sensors through either Normally Open or Normally Closed contacts. The pin assignment of the port is shown below.



Pin No.	Designation	Pin No.	Designation
1	Alarm Input 1	14	Ground
2	Alarm Input 2	15	Alarm Input 5
3	Alarm Input 3	16	Alarm Input 6
4	Alarm Input 4	17	Alarm Input 7
5	Sequence Timing Input	18	Alarm Input 8
6	Alarm Reset Output	19	Alarm Input 9
7	Ground	20	Ground
8	Alarm Recover Input	21	+5 V Output
9	Alarm Output	22	Recording Timer Select Input
10	Alarm Input 10	23	Alarm Input 14
11	Alarm Input 11	24	Alarm Input 15
12	Alarm Input 12	25	Alarm Input 16
13	Alarm Input 13		

- 48 Copy Port (COPY)**
For connecting the optional DVD-RAM Drive unit.
- 49 Mode Selector (MODE)**
Selects data termination for PS Data system expansion.
- 50 Data Port (DATA)**
Exchanges control data with the external device with PS Data (Panasonic Security Data) mode.
- 51 Remote Port [REMOTE (WV-CU50E)]**
This port is provided for controlling the Disk Recorder with the optional WV-CU50E Remote Controller. To connect to the controller, use a 6-conductor modular cable supplied as an accessory with the controller.

- 52 Serial Port (SERIAL)**
For connecting a Personal Computer.
- 53 Signal Ground Terminal (SIGNAL GND)**
- 54 10/100BASE-T Port (Optional)**
An optional Network Board can be installed in the Disk Recorder. This port is used to exchange control data with Ethernet via an Ethernet Hub.
- 55 Cooling Fan**
Prevents the temperature of the Recorder from rising. Do not block the ventilation opening on the cover.
- 56 AC Inlet Socket (AC IN)**
Plug the power cord (supplied as a standard accessory) into this socket and connect it to an AC outlet.
- 57 Power Switch (POWER ON/OFF)**
This switch turns the power of the Disk Recorder on and off.
- 58 Video Output Connectors (VIDEO OUT 1 - 16)**
The video signal connected to the Video Input Connector (VIDEO IN) is looped through these connectors with an automatic 75 Ω termination.
- 59 Video Input Connectors (VIDEO IN 1 - 16)**
These connectors accept either a colour or B/W composite video signal from the camera.

DIP SWITCH SETTING OF SCSI-IDE BOARD

- When replacing the SCSI-IDE Board, confirm that the #2, #3 and #8 of Dip Switch (SW1) on the SCSI-IDE Board are set to ON position as shown in Fig. 1




Fig. 1

ADJUSTMENT PROCEDURE

1. Test Equipments Required

- The following Test Equipments are required for adjustment of the Digital Disk Recorder WJ-HD500.
- Digital Voltmeter
- Frequency Counter
- Waveform Monitor
- Oscilloscope
- Underscanned Colour Video Monitor
- Video Signal Generator (Colour Bar Signal)
- Ceramic Screwdriver
- Extension Cable (A) (Part No.: V0EA1311AN) as shown in Fig. 1-1.




Fig. 1-1

- Extension Cable (B) (Part No.: V0AAG10AN) as shown in Fig. 1-2.



Fig. 1-2

2. Disassembling Procedure for Adjustment

- Referring to Fig. 2-1, remove eleven screws that secure the Top Cover and remove the Top Cover.




Fig. 2-1

- Referring to Fig. 2-2, remove six screws that secure the Main Board and disconnect CN403 on the Main Board.




Fig. 2-2

- Referring to Fig. 2-3, turn over the Main Board with the front side up.




Fig. 2-3

- Referring to Fig. 2-4, remove three screws that secure the Motion Detector Board and remove the Motion Detector Board.




Fig. 2-4

- Connect the Extension Cable (A) between CN403 on the Main Board and CN403 on the Front Board.
- Connect the Extension Cable (B) between CN501 on the Analog Board and CN501 on the Motion Detector Board.
- Connect the Extension Cable (B) between CN502 on the Analog Board and CN101 on the Motion Detector Board.

3. Connection and Setting Up for Adjustment

3.1. Connection

- Fig. 3-1 shows the connecting diagram for adjustment of the WJ-HD500.




Fig. 3-1

- Connect the Underscanned Colour Video Monitor through the Waveform Monitor to the Multiscreen Output Connector or Spot Output Connector on the Rear Panel of the WJ-HD500.
- Terminate the input terminal of the Underscanned Colour Video Monitor with 75 Ω.

- Connect the Video Signal Generator to the Video Input Connector on the Rear Panel of the WJ-HD500.
- Connect the probe of the Oscilloscope, the Frequency Counter and the Digital Voltmeter at the desired Test Point in each adjustment step.

3.2. Setting Up

- Turn on the power.
- Press the Setup/Escape Button (SET UP/ESC) for two seconds or more, and the WJ-HD500 SETUP menu as shown in Fig. 3-2 will appear on the monitor screen.




Fig. 3-2

- Move the cursor to **SYSTEM SETUP** by pressing the Direction Buttons (▲ or ▼), then press the Set Button (SET). The **SYSTEM SETUP** menu as shown in Fig. 3-3 will appear on the monitor screen.




Fig. 3-3

- Move the cursor to **USER DEFINED SETUP** by pressing the Direction Buttons (▲ or ▼).
- Select **SAVE** by pressing the Increment/Decrement Buttons (+ or -), then press the Set Button (SET). The **USER DEFINED SETUP** menu as shown in Fig. 3-4 will appear on the monitor screen.




Fig. 3-4

- Select **YES** by pressing the Direction Buttons (◀ or ▶), then press the Set Button (SET) to save the current setting conditions.
- When the saving is completed, press the Setup/Escape Button (SET UP/ESC) then the display will return to the **SYSTEM SETUP** menu as shown in Fig. 3-3.
- Press the Setup/Escape Button (SET UP/ESC) to return to the **WJ-HD500 SETUP** menu as shown in Fig. 3-5.




Fig. 3-5

- Move the cursor to **TIMER** by pressing the Direction Buttons (▲ or ▼).
- Select **INT** by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-5.
- Move the cursor to **REC SETUP/COMMON SETUP** by pressing the Direction Buttons (▲ or ▼), then press the Set Button (SET).
- The **COMMON REC SETUP** menu as shown in Fig. 3-6 will appear on the monitor screen.




Fig. 3-6

- Move the cursor to **CAMERA ASSIGNMENT** by pressing the Direction Buttons (▲ or ▼), then press the Set Button (SET). The **GROUP SETUP (CAMERA ASSIGNMENT)** menu as shown in Fig. 3-7 will appear on the monitor screen.




Fig. 3-7

- Move the cursor to the Group editing area for the **CAM 1** by pressing the Direction Buttons (▲ or ▼).
- Set the Group Number to 1 by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-7.
- Get the Group Number of the rest of Cameras to the number other than 1 by the same procedure as above.
- Press the Setup/Escape Button (SET UP/ESC) twice to return to the **WJ-HD500 SETUP** menu as shown in Fig. 3-5.
- Move the cursor to **REC SETUP/TIMER** by pressing the Direction Buttons (▲ or ▼).
- Select **WITHOUT AUDIO** by pressing the Increment/Decrement Buttons (+ or -), then press the Set Button (SET). The **TIMER REC SETUP** menu as shown in Fig. 3-8 will appear on the monitor screen.




Fig. 3-8

- Move the cursor to the Program editing area of **SUNDAY** in the menu by pressing the Direction Buttons (▲ or ▼).
- Set the Program Timer to --- (OFF) by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-8.
- Set the Program Timer of **MONDAY - SATURDAY** to --- (OFF) by the same procedure as above.
- Move the cursor to the Program editing area of **DAILY** in the menu by pressing the Direction Buttons (▲ or ▼).

- Set the Program Timer to **PROG1** by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-8.
- Press the Set Button (SET), and the **PROG1** setting menu as shown in Fig. 3-9 will appear on the monitor screen.




Fig. 3-9

- Move the cursor to the **START** time editing area of **NO.1** by the Direction Buttons (◀ or ▶, ▲ or ▼).
- Set the time to start the recording to 0:00 by the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-9.
- Move the cursor to the **END** time editing area of **NO.1** by the Direction Buttons (◀ or ▶).
- Set the time to end the recording to 24:00 by the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-9.
- Move the cursor to the Recording Mode editing area for Group 2 (G2) by pressing the Direction Buttons (◀ or ▶).
- Set the Recording Mode to --- (disable) by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-9.
- Set the Recording Mode of Group 3 (G3) and Group 4 (G4) to --- (disable) by the same procedure as above.
- Move the cursor to the Recording Mode editing area for Group 1 (G1) by pressing the Direction Buttons (◀ or ▶).
- Set the Recording Mode to **M/S** by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-9.
- Press the Set Button (SET), and the **M/S** setting menu as shown in Fig. 3-10 will appear on the monitor screen.




Fig. 3-10

- Move the cursor to the **REC RATE** in the menu by pressing the Direction Buttons (▲ or ▼).
- Set the Recording Rate to **15FPS** by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-10.

- Move the cursor to the **PRE PICTURES** by pressing the Direction Buttons (▲ or ▼).
- Set the number of the pre-recording image to the value other than 0 by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-10.
- Press the Setup/Escape Button (SET UP/ESC) three times to return to the **WJ-HD500 SETUP** menu as shown in Fig. 3-5.
- Move the cursor to **ALARM SETUP** by pressing the Direction Buttons (▲ or ▼), then press the Set Button (SET). The **ALARM SETUP** menu as shown in Fig. 3-11 will appear on the monitor screen.




Fig. 3-11

- Move the cursor to **VIDEO LOSS** by pressing the Direction Buttons (▲ or ▼).
- Select **OFF** by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-11.
- Move the cursor to **VIDEO MOTION DETECTION** by pressing the Direction Buttons (▲ or ▼).
- Select **OFF** by pressing the Increment/Decrement Buttons (+ or -) as shown in Fig. 3-11.
- Press the Setup/Escape Button (SET UP/ESC) for two seconds or more to close the setup menu and to return to the normal screen.
- Confirm that the Yellow LED of Numeric Button 1 only lights up.

4. Adjustment Procedure

- Refer to the Location of the Test Points and Adjusting Controls on the page 11.

■ Power Board

(1). +5V Adjustment

- Test Point: TP16 (+5V) Main Board
Adjust: VR2 (+5V) Power Board
- Turn on the power.
 - Connect the Digital Voltmeter to TP16.
 - Adjust VR2 to obtain 5.05 ± 0.05 V.

■ Main Board

(2). Real Time Clock Frequency Adjustment

- Test Point: TP21 (REAL TIME CLK) Main Board
Adjust: CT21 (REAL TIME CLK) Main Board
- Connect the Frequency Counter to TP21.
 - Adjust CT21 to obtain 32768.5 ± 0.03 Hz.
- Note: This Adjustment should be done within 2 minutes after turning on the power.

(3). Frame Memory Controller Frequency Adjustment

- Test Point: TP801 (FRAME MEMORY CLK) Main Board
Adjust: CT801 (FRAME MEMORY CLK) Main Board
- Connect the Frequency Counter to TP801.
 - Adjust CT801 to obtain $27 \text{ MHz} \pm 100$ Hz.

(4). Audio PLL Adjustment

- Test Point: TP802 (PLL) Main Board
Adjust: CT802 (PLL) Main Board
- Connect the Digital Voltmeter to TP802.
 - Adjust CT802 to obtain 1.65 ± 0.1 V.

(5). Multiscreen Output Level Adjustment

- Test Point: Multiscreen Output Connector Rear Panel
Adjust: VR751 (MULTI OUT) Main Board
- Connect the terminated Oscilloscope with 75Ω to the Multiscreen Output Connector.
 - Adjust VR751 so that the H-Sync Level becomes 300 ± 15 mV as shown in Fig. 4-1.




Fig 4-1

(6). Record Output Level Adjustment

- Test Point: Spot Output Connector Rear Panel
Adjust: VR701 (REC OUT) Main Board
- Supply the Colour Bar signal to the Video Input Connector 1.
 - Set the position of the SW11 on the Main Board to SUB side.
 - Connect the terminated Oscilloscope with 75Ω to Spot Output Connector.
 - Adjust VR701 so that the H-Sync Level becomes 300 ± 15 mV as shown in Fig. 4-1.

(7). Decoder Clamp Level Adjustment

- Test Point: TP601 (CLAMP-1) Main Board
TP602 (CLAMP-2) Main Board
TP603 (CLAMP-3) Main Board
Adjust: VR551 (CLAMP-1) Main Board
VR501 (CLAMP-2) Main Board
VR551 (CLAMP-3) Main Board
- Connect the Digital Voltmeter to TP601.
 - Adjust VR551 to obtain 0.60 ± 0.02 V.
 - Change the connection of the Digital Voltmeter to TP602.
 - Adjust VR501 to obtain 0.60 ± 0.02 V.
 - Change the connection of the Digital Voltmeter to TP603.
 - Adjust VR551 to obtain 0.60 ± 0.02 V.

■ Analog Board

(8). Decoder 1 and 2 Input Level Adjustment

- Test Point: Spot Output Connector Rear Panel
Adjust: VR811 (DECODER-1) Analog Board
VR821 (DECODER-2) Analog Board
- Supply the Stairstep signal (5 Steps, Chroma off) to the Video Input Connector 1.
 - Confirm the Position of SW11 on Main Board is SUB side.
 - Connect the terminated Oscilloscope with 75Ω to the Spot Output Connector.

- Adjust VR811 and VR821 so that the 700 mV portion of the Stairstep signals becomes 700 ± 15 mV as shown in Fig. 4-2.




Fig 4-2

(9). Decoder 3 Input Level Adjustment

- Test Point: Multiscreen Output Connector Rear Panel
Adjust: VR631 (DECODER-3) Analog Board
- Supply the Stairstep signal (5 Steps, Chroma off) to the Video Input Connector 1.
 - Connect the terminated Oscilloscope with 75Ω to the Multiscreen Output Connector.
 - Press the Numeric Button 1.
 - Adjust VR631 so that the 700 mV portion of the Stairstep signal becomes 700 ± 15 mV as shown in Fig. 4-2.

■ Motion Detector Board

- Set the #5 and #8 of SW23 on the Main Board to ON position as shown in Fig. 4-3.



Fig 4-3

- Turn on the power.

(10). G/L PLL DC Adjustment

- Test Point: TP601 (G/L PLL DC-1) Motion Detector Board
TP602 (G/L PLL DC-2) Motion Detector Board
Adjust: L607 (G/L PLL DC-1) Motion Detector Board
L608 (G/L PLL DC-2) Motion Detector Board
- Supply the Ramp signal to the Video Input Connector 1.
 - Connect the Digital Voltmeter to TP601.
 - Adjust L607 to obtain 2.5 ± 0.1 V.
 - Connect the Digital Voltmeter to TP602.
 - Adjust L608 to obtain 2.5 ± 0.1 V.

(11). Pedestal Adjustment

- Test Point: TP101 (Y-1) Motion Detector Board
TP201 (Y-2) Motion Detector Board
Adjust: VR101 (Y.PED-1) Motion Detector Board
VR201 (Y.PED-2) Motion Detector Board
- Supply the White Raster signal to the Video Input Connector 1.
 - Set the #1 of SW601 on the Motion Detector Board to ON position as shown in Fig. 4-4.



Fig 4-4

- Set the Luminance Level of input signal to 0 mV.
- Connect the Digital Voltmeter to TP101.
- Adjust VR101 to obtain 0.7 ± 0.1 V.
- Connect the Digital Voltmeter to TP201.
- Adjust VR201 to obtain 0.7 ± 0.1 V.

(12). Y Level Adjustment

- Test Point: TP101 (Y-1) Motion Detector Board
TP201 (Y-2) Motion Detector Board
Adjust: VR102 (Y.GAIN-1) Motion Detector Board
VR202 (Y.GAIN-2) Motion Detector Board
- Supply the White Raster signal to the Video Input Connector 1.
 - Set the Luminance Level of input signal to 700 mV.
 - Connect the Digital Voltmeter to TP101.
 - Adjust VR102 to obtain 2.4 ± 0.2 V.
 - Connect the Digital Voltmeter to TP201.
 - Adjust VR202 to obtain 2.47 ± 0.2 V.


- After completing of the adjustment, set the #1 and #2 of SW601 to OFF position as shown in Fig. 4-5.




Fig 4-5

LOCATION OF TEST POINTS AND ADJUSTING CONTROLS


MAIN BOARD (COMPONENT SIDE)





POWER BOARD (COMPONENT SIDE)







ANALOG BOARD (COMPONENT SIDE)




MOTION DETECTOR BOARD (COMPONENT SIDE)





BLOCK DIAGRAM OF MAIN BOARD (3/10)


MAIN BOARD (3/10)



- 10 -

BLOCK DIAGRAM OF MAIN BOARD (4/10)/(5/10)

MAIN BOARD (4/10)/(5/10)




- 11 -

BLOCK DIAGRAM OF MAIN BOARD (6/10) / REAR BOARD

MAIN BOARD (6/10)


REAR BOARD



- 12 -


BLOCK DIAGRAM OF MAIN BOARD (7/10)

MAIN BOARD (7/10)




- 13 -

BLOCK DIAGRAM OF MAIN BOARD (8/10)(9/10)




-21-

BLOCK DIAGRAM OF MAIN BOARD (8/10)(10/10)




-22-

BLOCK DIAGRAM OF MOTION DETECTOR BOARD



-23-

CONDUCTOR VIEW OF ANALOG BOARD



-24-

[illegible][illegible]

Figure 1 consists of two photographs of a rear board layout, labeled (A) and (B).
 (A) Internal side view: This photograph shows the underside of the board. It features a large integrated circuit labeled 'J4500JRIC' in the center. To the left, there are several connectors and components, including a 'J4500JRIC' label. To the right, there are more connectors and components, including a 'J4500JRIC' label. The board is populated with various electronic components, including resistors, capacitors, and integrated circuits.
 (B) External side view: This photograph shows the top of the board. It features a large integrated circuit labeled 'J4500JRIC' in the center. To the left, there are several connectors and components, including a 'J4500JRIC' label. To the right, there are more connectors and components, including a 'J4500JRIC' label. The board is populated with various electronic components, including resistors, capacitors, and integrated circuits.

MOTION DETECTOR BOARD (1/2)

SECTION A

SECTION B

LEGEND

Symbol	Description
[Symbol]	RESISTOR
[Symbol]	CAPACITOR
[Symbol]	TRANSISTOR
[Symbol]	DIODE
[Symbol]	RELAY
[Symbol]	SWITCH
[Symbol]	INDUCTOR
[Symbol]	CONNECTOR
[Symbol]	GROUND


COMPONENT VALUES

Value	Value	Value	Value
10K	100K	1M	10M
100K	1M	10M	100M
1M	10M	100M	1G
10M	100M	1G	10G
100M	1G	10G	100G
1G	10G	100G	1T
10G	100G	1T	10T
100G	1T	10T	100T
1T	10T	100T	1000T


COMPONENT TYPES

Value	Value	Value	Value
10K	100K	1M	10M
100K	1M	10M	100M
1M	10M	100M	1G
10M	100M	1G	10G
100M	1G	10G	100G
1G	10G	100G	1T
10G	100G	1T	10T
100G	1T	10T	100T
1T	10T	100T	1000T


SCHEMATIC DIAGRAM OF MOTION DETECTOR BOARD (2/2)




CONDUCTOR VIEW OF MOTION DETECTOR BOARD




SCHEMATIC DIAGRAM OF MAIN BOARD (1/10)




SCHEMATIC DIAGRAM OF MAIN BOARD (2/10)




SCHEMATIC DIAGRAM OF MAIN BOARD (3/10)




SCHEMATIC DIAGRAM OF MAIN BOARD (4/10)



SCHEMATIC DIAGRAM OF MAIN BOARD (5/10)



SCHEMATIC DIAGRAM OF MAIN BOARD (6/10)



MAIN BOARD (7/10)



MAIN BOARD (8/10)




MAIN BOARD (9/10)




MAIN BOARD (10:10)




CONDUCTOR VIEW OF MAIN BOARD




CONDUCTOR VIEW OF FRONT BOARD / LED BOARD





SCHEMATIC DIAGRAM OF FRONT BOARD / LED BOARD



SCHEMATIC DIAGRAM OF POWER BOARD





REPLACEMENT PARTS LIST

Important Notice

- Components identified by "△" mark have special characteristics important for safety.
When replacing any of these components, use only manufacturer's specified parts.
- RT1 : Retention Time 1 limited (No longer available after discontinuing product)

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
MISCELLANEOUS					
L101,102	J0K000000029	Flat Core	M9	29T01	Gear (x3)
BA11	VL2330-1554	Lithium battery	M10	V2SA4980A4	Local Holding Plate A
M01	YWB4A66A12H	Cooling Fan	M11	V2SA4984A4	Local Holding Plate B
E102	JH05.00000001	AC Main Socket	M12	YVW6JB1156A3	Button
E103	K92200000753	Flat Cable for Main Board CN11 and Analog Board CN11	M13	YVW6JA1157A3	Button
F104	K97700000754	Flat Cable for Main Board CN17 and Rear Board CN12	M14	YVW6JA1156A3	Button
E105	JHD500L01A	Wire Assy for SCSI-IDE Board CN8 and Hard Disk	M15	V6JB1184A3	Step Button
E106	JHD500L02A	Wire Assy for Main Board CN404 and SCSI-IDE Board CN1	M16	V6JB1184A3	Play/Pause Button
E107	JHD500L03A	Wire Assy for Main Board CN405 and Front Board CN403	M17	V6JC1157A3	Recent Button
E108	JHD500L04A	Wire Assy for Main Board CN402 and Rear Board CN402	M18	V2SA4901A1	Mounting Angle for Front Board
E109	JHD500L05A	Wire Assy for Main Board CN13 and Analog Board CN13	M19	V5WB2619A1	Front Panel
E110	JHD500L06A	Wire Assy for Analog Board CN701 and MO1	M20	YWB1VA0546A3	LED Lens
E111	JHD500L07A	Wire Assy for Analog Board CN16 and SCSI-IDE Board CN2	M21	V2NA1137A3	LED Lens Holder
E112	JHD500L08B	Wire Assy for Main Board CN14 and Analog Board CN15	M22	YB127K	Cord Clamp
E113	JHD500L09B	Wire Assy for Power Board CN1 and E102	M23	VWCS4	Cord Clamp
E114	JHD500L11B	Wire Assy for Analog Board CN17 and Power Board E11	M24	V2NA1133A1	Front Chassis
E115	JHD500L12A	Wire Assy for Main Board CN14 and Power Board CN2	M25	V2PA1277A3	Insulator Sheet
E116	JHD500L13A	Wire Assy for Main Board CN15 and Power Board CN4	M26	V0EA1320A0N	Hard Disk
E117	JHD500L14A	Wire Assy for E102 and Main Chassis	M27	V1EA1041A4	Hard Disk Fixing Screw (x4)
E118	K1PA50000001	Cable Assy for Main Board CN301, SCSI-IDE Board CN3 and Extension Storage Port	M28	V1BA0505A4	Sleeve (x4)
E119	K1PA50000002	Cable Assy for Main Board CN351 and Copy Port	M29	V2PA1266A4	Absorber (x4)
M1	V5EA2463A3	Control Panel Lid	M30	V2SA4905A3	Tray Chassis
M2	V3KA00130A4	Magnet	M31	YVW2HA2167A4	Cushion (x2)
M3	V7SC4215A3	Operation Sheet	M32	EMT2N	Cord Clamp
M4	YVW1AA1074A4	Standard Screw (x10)	M33	V2HB2186A4	Cushion
M5	V2SA4986A4	Mounting Angle for Magnet	M34	V2SA4902A2	Sub Chassis A
M6	V5RA1082C3	Jug Dial	M35	V2SA4937A3	Reinforcement
M7	V5RA1081C3	Shuffle Ring	M36	VWE051	Cord Clamp
M8	V2VW50A18A1	Control Panel	M37	V2SA4903A2	Sub Chassis B
			M38	V2SA4923A3	Sub Chassis C
			M39	YWE1000EM02	Standard Screw
			M40	V2EA2600A1	Top Cover
			M41	V2FB1313A4	Spiral Tube
			M42	V2BK2167A4	Cushion (x4)
			M43	V2KA1340A1	Cushion (x4)
			M44	VWVLA0067A4	Rubber Foot (x4)
			M45	VWVLA0070A4	Joint (x4)
			M46	V4JA1159A4	Earth Lug
			M47	V2FB1328A4	Cushion (x2)
			M48	V7DA1155A2	Heat Sink
			M49	V2FA1323A4	Cushion (x5)
			M50	V2DA1154A3	Heat Sink
			M51	V2SA4904A3	Mounting Angle for Main Board
			M52	BSB312	Spacer
			M53	FRC12CP	Holder for Flat Core
			M54	V2SA4909A3	Mounting Angle
			M55	V5WB2617A1	Rear Panel
			M56	VWASD0020A3	Switch Guard
			M57	VWASD0011A3	Power Switch Knob
			M58	VWV2SA2796A4	Mounting Angle for Cooling Fan
			M59		

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
M60	V2SA4908B4	Mounting Angle for Cooling Fan	IC391	COJBAE000227	IC
M61	V5EA2471A4	10/100BASE-T Port Cover	IC392	COJBAZ001492	IC
M62	JF32.65010M	O 3x4 Screw	IC393	COJBAZ000037	IC
M71	V7DA0500A4	Main Label	IC411	COJBAZ001492	IC
M72	V7SA4171A4	PS Data Label	IC412	COJBAE000383	IC
M73	YFYJMB0099A4	Safety Label	IC414	COJBAE000037	IC
M75	V7SA4244A4	Caution Label	IC416	C10B00000246	IC
M76	V7SA4303A4	Mode Selector Setting Label	IC417,418	YLTC491CS-TR	IC
M77	YWA75A0689A4	Earth Mark Label	IC419	74HC4538ADTE	IC
M79	V7SA4315B4	Hard Disk Change Label	IC424	COJBAE000224	IC
			IC425	COJBAZ001502	IC
			IC426	COJBAE000234	IC
			IC427	COJBAZ001492	IC
			IC428,429	COJBAE000257	IC
			IC430,431	YWTL16550CPT	IC
			IC432	COJBAE000381	IC
			IC504	YVWJM2244M	IC
			IC505	COJBAZ000138	IC
			IC551	C1A800001141	IC
			IC552	COJBAZ000865	IC
MAIN BOARD					
PCB1 (RTL)	JH500K21A	Printed Circuit Board Assy	IC557	YWBAD33FPE2	IC
IC11	COJBAE0000379	IC	IC558	YWBAD33FPE2	IC
IC21	COJBAE0000379	IC	IC559	YWBAD33FPE2	IC
IC22	COJBAZ000994	IC	IC560	YWBAD33FPE2	IC
IC23	COJBAE000094	IC	IC561	YWBAD33FPE2	IC
IC24	COJBAE000014	IC	IC562	YWBAD33FPE2	IC
IC25	COJBAF000075	IC	IC563	YWBAD33FPE2	IC
IC26-29	COJBAF000280	IC	IC564	COJBAE000381	IC
IC31	COJBAZ000158	IC	IC565	COJBAZ000865	IC
IC32	C2D0Y 3000002	IC	IC566	YWBUT4254K	IC
IC33		IC	IC701,751		
IC36		IC	IC752	COJBAE000282	IC
IC36.37	C3AB0G000015	IC	IC754	YVWJM2244M	IC
IC38	COJBAZ000095	IC	IC755	COJBAE000158	IC
IC39.40	COJBAZ001497	IC	IC756	COJBAF000250	IC
IC41-43	COJBAZ000785	IC	IC801	C1A800001204	IC
IC44	COJBAE0000380	IC	IC802	C3ABFG000008	IC
IC45		IC	IC803	YVMD33653XT	IC
IC46	C3B0K0000022	IC	IC804	COJBAZ000029	IC
IC47	YWPCT00017	IC	IC805	COJBAZ000865	IC
IC48	COJBAZ000865	IC	IC806	COJBC0002057	IC
IC49	COJBAZ000158	IC	IC807	C1AA00000582	IC
IC50	COJBAZ001497	IC	IC808,809	COJBAE000257	IC
IC51	COJBAZ000865	IC	IC810	COJBAE000382	IC
IC52	COJBAZ001497	IC	IC811	COJBAZ000029	IC
IC53	COJBAZ000786	IC	IC814,815	COJBAF000387	IC
IC55	COJBEF700001	IC	IC816	C87000000332	IC
IC56	COJBAE000196	IC	IC817	COJBAE000032	IC
IC57	74HC4538ADTE	IC	IC818	YWTC7704FUL	IC
IC201	C1A800001205	IC	IC819	COJBAZ001492	IC
IC202,203	C3AB0G000015	IC	IC820	COJBAE000256	IC
IC210	COJBAE0000356	IC	IC822	COJBAE000224	IC
IC212,213	COJBAZ0000250	IC	IC823	COJBAE000027	IC
IC301	C1D0B0000480	IC	IC827	COJBAE000407	IC
IC341	AN8012NSB-E1	IC	IC901	C1A800001204	IC
IC351	C1D0B0000480	IC	IC902	C3ABFG000008	IC

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
IK903	YWM305053XT	IC	R60-62	ERJGEY1J03V	Metal 10K ohms 1/16W
IK904	CU8A2001504	IC	R63-66	ERJGEY1J220V	Metal 22 ohms 1/16W
IK905	CU8A2000805	IC	R67-74	ERJGEY1J03V	Metal 10K ohms 1/16W
IK906	CU8C2000057	IC	R75	ERJGEY1J513V	Metal 51K ohms 1/16W
IK907	C1A40000582	IC	R76-106	ERJGEY1J243V	Metal 24K ohms 1/16W
IK908	CU8AA000257	IC	R77	ERJGEY1J01V	Metal 100 ohms 1/16W
IK909	CU8AA000256	IC	R78-81	ERJGEY0R000	Metal 0 ohm 1/16W
IK913	C1A000001143	IC	R82	D18B10R00001	Metal 10 ohms 1/16W
IK915	CU8AA000257	IC	R83-86	ERJGEY0R000	Metal 0 ohm 1/16W
IK922	CU8AE0000224	IC	R87	ERJGEY1J03V	Metal 10K ohms 1/16W
IK293	YW17C7566UL	IC	R88-91	ERJGEY0R000	Metal 0 ohm 1/16W
Q21	ERJGEY00004	Transistor	R93-98	ERJGEY0R000	Metal 0 ohm 1/16W
Q22-37	Z5D1819-R5TX	Transistor	R99-101	ERJGEY1J220V	Metal 22 ohms 1/16W
Q38	E5C5009-R5TX	Transistor	R102	ERJGEY1J330V	Metal 33 ohms 1/16W
Q39-40	Z5K122800L	Transistor	R103-105	ERJGEY1J220V	Metal 22 ohms 1/16W
Q41	Z5D1819-R5TX	Transistor	R106	FR13CFY1J330V	Metal 33 ohms 1/16W
Q341	Z5B1218-R5TX	Transistor	R107-110	ERJGEY1J220V	Metal 22 ohms 1/16W
Q342	Z5K122800L	Transistor	R111-112	ERJGEY1J03V	Metal 10K ohms 1/16W
Q343	Z5D1819-R5TX	Transistor	R113	ERJGEY1J00V	Metal 10 ohms 1/16W
Q3503	Z5B1218-R5TX	Transistor	R114-116	ERJGEY1J330V	Metal 33 ohms 1/16W
Q504	Z5D1819-R5TX	Transistor	R117-118	ERJGEY1J66V	Metal 56 ohms 1/16W
Q505-508	Z5B1218-R5TX	Transistor	R119-120	ERJGEY1J220V	Metal 22 ohms 1/16W
Q701-706	Z5B1218-R5TX	Transistor	R121-126	ERJGEY1J03V	Metal 10K ohms 1/16W
Q751	Z5B1218-R5TX	Transistor	R127-131	ERJGEY0R000	Metal 0 ohm 1/16W
Q752	Z5D1819-R5TX	Transistor	R132-133	ERJGEY1J03V	Metal 10K ohms 1/16W
Q753	Z5B1218-R5TX	Transistor	R134-141	ERJGEY0R000	Metal 0 ohm 1/16W
Q754	Z5D1819-R5TX	Transistor	R142	ERJGEY1J220V	Metal 22 ohms 1/16W
Q755-756	Z5B1218-R5TX	Transistor	R143-145	ERJGEY1J03V	Metal 10K ohms 1/16W
Q801	Z5D1819-R5TX	Transistor	R146-150	ERJGEY1J03V	Metal 10K ohms 1/16W
Q802	B1C28F000007	Transistor	R151	YWR0816P401D	Metal 300 ohms 1/16W
Q901	Z5D1819-R5TX	Transistor	R152	D18B36010001	Metal 3.6K ohms 1/16W
Q902	Z5B1218-R5TX	Transistor	R153-154	ERJGEY1J03V	Metal 10K ohms 1/16W
Q93-99	LM4041CTR	IC	R155-157	ERJGEY1J220V	Metal 22 ohms 1/16W
D40-41	80DAC2000001	Diode	R158	D18B60000001	Metal 62 ohms 1/16W
D42-43	MAX3152A0L	Diode	R159	YWR0816P121D	Metal 12 ohms 1/16W
D801	YWRU035010F	Diode	R160	ERJGEY1J02V	Metal 1K ohms 1/16W
D9998-9999	MA178	Diode	R161-162	ERJGEY0R000	Metal 0 ohm 1/16W
TH401	ERY32S050VA	Thermistor	R164-167	ERJGEY0R000	Metal 0 ohm 1/16W
R1	ERJGEY1J03V	Metal 10K ohms 1/16W	R168	ERJGEY1J03V	Metal 10K ohms 1/16W
R2	ERJGEY0R000	Metal 0 ohm 1/16W	R169-170	ERJGEY0R000	Metal 0 ohm 1/16W
R3	ERJGEYJ514	Metal 510K ohms 1/16W	R171	ERJGEY1J03V	Metal 10K ohms 1/16W
R4	ERJGEY1J03V	Metal 10K ohms 1/16W	R174	D18B39R00001	Metal 39 ohms 1/16W
R5-21	ERJGEY0R000	Metal 0 ohm 1/16W	R175	YWR0816P471D	Metal 470 ohms 1/16W
R22	ERJGEY1J03V	Metal 10K ohms 1/16W	R177-181	ERJGEY1J220V	Metal 22 ohms 1/16W
R23-25	ERJGEY1J03V	Metal 10K ohms 1/16W	R182-184	ERJGEY1J03V	Metal 10K ohms 1/16W
R26-77	FR13CFY0R000	Metal 0 ohms 1/16W	R185	FR13CFY1J29V	Metal 27 ohms 1/16W
R28	ERJGEY1J03V	Metal 10K ohms 1/16W	R186	ERJGEY1J03V	Metal 10K ohms 1/16W
R29	ERJGEY0R000	Metal 0 ohm 1/16W	R187	ERJGEY1J220V	Metal 22 ohms 1/16W
R30	D18B12030001	Metal 120K ohms 1/16W	R188-191	ERJGEY0R000	Metal 0 ohm 1/16W
R31	ERJGEY1J02V	Metal 2K ohms 1/16W	R193-196	ERJGEY0R000	Metal 0 ohm 1/16W
R32-34	ERJGEY1J03V	Metal 10K ohms 1/16W	R197-201	ERJGEY1J03V	Metal 10K ohms 1/16W
R36-42	ERJGEY1J22V	Metal 10K ohms 1/16W	R202	ERJGEY1J02V	Metal 1K ohms 1/16W
R44-43	ERJGEY1J03V	Metal 10K ohms 1/16W	R203-206	ERJGEY1J22V	Metal 22 ohms 1/16W
R54	ERJGEY1J02V	Metal 1K ohms 1/16W	R207	ERJGEY1J03V	Metal 10K ohms 1/16W
R57-59	ERJGEY1J03V	Metal 10K ohms 1/16W	R208	ERJGEY1J01V	Metal 100 ohms 1/16W

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R764-765	ERJGEY1J23V	Metal 22K ohms 1/16W	R924-926	ERJGEY1J03V	Metal 10K ohms 1/16W
R766	YWR0816P752D	Metal 7.5K ohms 1/16W	R927-928	ERJGEY1J03V	Metal 47 ohms 1/16W
R767	YWR0816P722D	Metal 2.2K ohms 1/16W	R930	YWR0816P100V	Metal 10 ohms 1/16W
R768	YWR0816P422D	Metal 2.4K ohms 1/16W	R931-932	ERJGEY0R000	Metal 0 ohm 1/16W
R769-770	ERJGEY1J01V	Metal 390 ohms 1/16W	R933-934	ERJGEY1J03V	Metal 10K ohms 1/16W
R771	ERJGEY1J02V	Metal 1K ohms 1/16W	R935-936	ERJGEY1J02V	Metal 1K ohms 1/16W
R772	ERJGEY1J03V	Metal 10K ohms 1/16W	R941	YWR0816P100V	Metal 10 ohms 1/16W
R773	ERJGEY1J02V	Metal 47 ohms 1/16W	R945	ERJGEY1J03V	Metal 10K ohms 1/16W
R777	ERJGEY1J03V	Metal 22K ohms 1/16W	R946-947	ERJGEY1J03V	Metal 10K ohms 1/16W
R788	ERJGEY1J01V	Metal 100 ohms 1/16W	R951-954	ERJGEY1J03V	Metal 10K ohms 1/16W
R789	ERJGEY0R000	Metal 0 ohm 1/16W	R956-958	ERJGEY1J03V	Metal 10K ohms 1/16W
R790	ERJGEY1J22V	Metal 2.2K ohms 1/16W	R959	ERJGEY0R000	Metal 0 ohm 1/16W
R801-804	ERJGEY1J03V	Metal 10K ohms 1/16W	R964	ERJGEY1J23V	Metal 27K ohms 1/16W
R805-806	CRJGEYJ470V	Metal 47 ohms 1/16W	R965	ERJGEY1J223V	Metal 22K ohms 1/16W
R807-810	ERJGEY0R000	Metal 0 ohm 1/16W	R967	ERJGEY1J02V	Metal 1K ohms 1/16W
R811	ERJGEYJ40V	Metal 47 ohms 1/16W	R968	FR13CFY1J21V	Metal 270 ohms 1/16W
R812	ERJGEYJ330V	Metal 33 ohms 1/16W	R969	ERJGEYJ331V	Metal 33 ohms 1/16W
R815-820	ERJGEYJ470V	Metal 47 ohms 1/16W	R970	ERJGEY1J32V	Metal 1.3K ohms 1/16W
R822	ERJGEY1J03V	Metal 10K ohms 1/16W	R971	ERJGEY1J250V	Metal 75 ohms 1/16W
R823	ERJGEYJ470V	Metal 47 ohms 1/16W	R972	ERJGEY1J02V	Metal 1K ohms 1/16W
R824	ERJGEY1J03V	Metal 10K ohms 1/16W	R973	ERJGEY1J221V	Metal 220 ohms 1/16W
R826	YWR0816P100V	Metal 10 ohms 1/16W	R974-1,100V	YWR0816P100V	Metal 10 ohms 1/16W
R827-828	ERJGEYJ470V	Metal 47 ohms 1/16W	R1003-1006	ERJGEY0R000	Metal 0 ohm 1/16W
R830	ERJGEY1J03V	Metal 10K ohms 1/16W	WV551-601	EW1D5W30814	Semifield Resistor 10K ohms
R831-832	ERJGEY0R000	Metal 0 ohm 1/16W	WV651-701	EW1D5W30814	Semifield Resistor 10K ohms
R833-834	ERJGEY1J03V	Metal 10K ohms 1/16W	VR751	EW1D5W30813	Semifield Resistor 1K ohms
R835-836	FR13CFY1J03V	Metal 1K ohms 1/16W	VR751-1000	YWR0816P100V	Metal 10 ohms 1/16W
R837	ERJGEY1J03V	Metal 47 ohms 1/16W	Z26-35	YWMNR14EJ220	Block Resistor 22 ohms
R838	ERJGEY1J05V	Metal 1M ohms 1/16W	Z36-39	D1H8470A0008	Block Resistor 47 ohms
R840	ERJGEYJ332V	Metal 3.3K ohms 1/16W	Z40-43	D1H8100A0003	Block Resistor 10 ohms
R841	ERJGEY0R000	Metal 0 ohm 1/16W	Z44-57	YWMNR14EJ103	Block Resistor 10K ohms
R842	ERJGEY1J05V	Metal 1M ohms 1/16W	Z62	YWMNR14EJ391	Block Resistor 390 ohms
R843	ERJGEY1J03V	Metal 10K ohms 1/16W	Z63	YWMNR14EJ103	Block Resistor 10K ohms
R845	ERJGEYJ470V	Metal 47 ohms 1/16W	Z64	YWMNR14EJ103	Block Resistor 390 ohms
R846-847	ERJGEY1J50V	Metal 75 ohms 1/16W	Z65	YWMNR14EJ103	Block Resistor 10K ohms
R848	ERJGEYJ332V	Metal 3.3K ohms 1/16W	Z66	YWMNR14EJ391	Block Resistor 390 ohms
R849	ERJGEY1J03V	Metal 10K ohms 1/16W	Z67	YWMNR14EJ103	Block Resistor 10K ohms
R850	ERJGEY1J05V	Metal 1M ohms 1/16W	Z68	YWMNR14EJ391	Block Resistor 390 ohms
R851	ERJGEY0R000	Metal 0 ohm 1/16W	Z69-78	YWMNR14EJ103	Block Resistor 10K ohms
R852-854	ERJGEYJ470V	Metal 47 ohms 1/16W	Z88-91	D1H8800A0001	Block Resistor 68 ohms
R855-856	ERJGEY1J00V	Metal 10 ohms 1/16W	Z92-95	D1H8470A0008	Block Resistor 47 ohms
R857	Block Resistor	Metal 0 ohms 1/16W	Z96-122	YWMNR14EJ220	Block Resistor 22 ohms
R858-860	CRJGEY0R00V	Metal 0 ohms 1/16W	Z123-130	YWMNR14EJ103	Block Resistor 10K ohms
R861	CRJGEY1J03V	Metal 10K ohms 1/16W	Z131-154	YWMNR14EJ220	Block Resistor 22 ohms
R862-866	ERJGEY1J03V	Metal 10K ohms 1/16W	Z155-158	YWMNR14EJ103	Block Resistor 10K ohms
R867-868	ERJGEY0R000	Metal 0 ohm 1/16W	Z161-169	YWMNR14EJ220	Block Resistor 22 ohms
R873	ERJGEY1J01V	Metal 10 ohms 1/16W	Z170-173	YWMNR14EJ103	Block Resistor 10K ohms
R874	ERJGEY1J03V	Metal 10K ohms 1/16W	Z174-175	YWMNR14EJ220	Block Resistor 22 ohms
R891-894	ERJGEYJ470V	Metal 47 ohms 1/16W	Z177	YWMNR14EJ103	Block Resistor 22 ohms
R905-906	ERJGEY0R000	Metal 0 ohm 1/16W	Z178-199	YWMNR14EJ103	Block Resistor 10K ohms
R907-910	ERJGEY1J03V	Metal 10K ohms 1/16W	Z201-203	YWMNR14EJ1000	Block Resistor 0 ohm
R912	YWMNR14EJ103	Metal 10K ohms 1/16W	Z208-213	YWMNR14EJ220	Block Resistor 22 ohms
R915-917	ERJGEYJ470V	Metal 47 ohms 1/16W	Z215-219	YWMNR14EJ220	Block Resistor 22 ohms
R919-921	ERJGEYJ470V	Metal 47 ohms 1/16W	Z220-242	YWMNR14EJ1000	Block Resistor 0 ohm
R922-923	ERJGEYJ470V	Metal 47 ohms 1/16W	Z243-248	YWMNR14EJ103	Block Resistor 10K ohms

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R211-256	ERJGEY1J00V	Metal 0 ohms 1/16W	R473-474	ERJGEY0R000	Metal 0 ohm 1/16W
R257-259	ERJGEY0R00V	Metal 0 ohm 1/16W	R475	ERJGEY0R000	Metal 0 ohm 1/16W
R260	ERJGEY1J03V	Metal 10K ohms 1/16W	R476	ERJGEY1J03V	Metal 10K ohms 1/16W
R261	ERJGEY1J20V	Metal 2K ohms 1/16W	R478-482	ERJGEY0R000	Metal 0 ohm 1/16W
R262	ERJGEY1J03V	Metal 10K ohms 1/16W	R484	ERJGEY1J03V	Metal 10K ohms 1/16W
R263	ERJGEY1J32V	Metal 3.3K ohms 1/16W	R485	ERJGEY0R000	Metal 0 ohm 1/16W
R264	ERJGEY1J23V	Metal 22K ohms 1/16W	R506	ERDS2T1J02	Metal 1K ohms 1/16W
R265	ERJGEY1J04V	Metal 100K ohms 1/16W	R507	ERJGEY1J01V	Metal 100 ohms 1/16W
R266	ERJGEY1J22V	Metal 2.2K ohms 1/16W	R508	ERJGEY1J02V	Metal 10K ohms 1/16W
R267	ERJGEY0R000	Metal 0 ohm 1/16W	R510	ERJGEY1J22V	Metal 2.2K ohms 1/16W
R269	ERJGEY1J00V	Metal 20 ohms 1/16W	R511	ERJGEY1J01V	Metal 100 ohms 1/16W
R281-304	ERJGEY1J03V	Metal 10K ohms 1/16W	R512	ERJGEY1J54V	Metal 150K ohms 1/16W
R305-307	ERJGEY1J22V	Metal 2.2K ohms 1/16W	R513	ERJGEY1J22V	Metal 2.2K ohms 1/16W
R308	CRJGEYJ470V	Metal 4.7K ohms 1/16W	R514	CRJGEYJ283V	Metal 28K ohms 1/16W
R309-310	ERJGEY0R000	Metal 0 ohm 1/16W	R516	YWR0816P22D	Metal 2.2K ohms 1/16W
R311	FR13CFY1J21V	Metal 270 ohms 1/16W	R517	YWR0816P151D	Metal 1.5K ohms 1/16W
R313	ERJGEY1J31V	Metal 330 ohms 1/16W	R518	YWR0816P162D	Metal 1.6K ohms 1/16W
R315	ERJGEY0R000	Metal 0 ohm 1/16W	R519-520	ERJGEY1J01V	Metal 100 ohms 1/16W
R341	ERJGEY1J04V	Metal 100K ohms 1/16W	R521	ERJGEY1J02V	Metal 1K ohms 1/16W
R342	ERJGEYJ473V	Metal 47K ohms 1/16W	R522	ERJGEY1J01V	Metal 100 ohms 1/16W
R343	ERJGEY1J32V	Metal 3.3K ohms 1/16W	R523	ERJGEY1J02V	Metal 1K ohms 1/16W
R344	ERJGEY0R000	Metal 0 ohm 1/16W	R525	ERJGEY1J01V	Metal 100 ohms 1/16W
R351-354	ERJGEY1J03V	Metal 10K ohms 1/16W	R526	ERJGEY1J02V	Metal 1K ohms 1/16W
R355-357	ERJGEY1J22V	Metal 2.2K ohms 1/16W	R527	ERJGEY0R000	Metal 0 ohm 1/16W
R368	ERJGEYJ472V	Metal 4.7K ohms 1/16W	R528	ERJGEY1J01V	Metal 100 ohms 1/16W
R359-360	ERJGEY0R000	Metal 0 ohm 1/16W	R551-553	ERJGEY0R000	Metal 0 ohm 1/16W
R361-362	ERJGEY1J21V	Metal 220 ohms 1/16W	R555	ERJGEY0R000	Metal 0 ohm 1/16W
R363-364	ERJGEY1J331V	Metal 330 ohms 1/16W	R556-559	ERJGEY1J03V	Metal 10K ohms 1/16W
R365	ERJGEY0R000	Metal 0 ohm 1/16W	R561-598	ERJGEYJ470V	Metal 47 ohms 1/16W
R366	ERJGEY1J22V	Metal 2.2K ohms 1/16W	R599	ERJGEY1J03V	Metal 10K ohms 1/16W
R367	ERJGEY1J31V	Metal 330 ohms 1/16W	R605	ERJGEY0R000	Metal 0 ohm 1/16W
R368-369	ERJGEY1J03V	Metal 10K ohms 1/16W	R606-609	ERJGEY1J03V	Metal 10K

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
C425	MCUVIE104ZFV	Ceramic	C613	MCUVIE104ZFV	Ceramic
C426	ECSTIC336R	Tantalum	C614	F2G1C100002	Electrolytic
C428	EEVHB0330R	Electrolytic	C615	F1HH10A013	Ceramic
C429	MCUVIE104ZFV	Ceramic	C616	MCUVIE104ZFV	Ceramic
C430.431	MCUVIE104ZFV	Ceramic	C617	F2G1CA70003	Electrolytic
C432	EEVHB0220R	Electrolytic	C618-620	MCUVIE104ZFV	Ceramic
C433.434	MCUVIE104ZFV	Ceramic	C621	F2G1CA70003	Electrolytic
C435	EEVHB0180R	Electrolytic	C622-624	MCUVIE104ZFV	Ceramic
C436.437	MCUVIE104ZFV	Ceramic	C625	F2G0J101002	Electrolytic
C438	F1HH10A004	Ceramic	C626.627	MCUVIE104ZFV	Ceramic
C439	MCUVIE104ZFV	Ceramic	C637	F1HH10A013	Ceramic
C441	F1HH10A001	Ceramic	C638	MCUVIE104ZFV	Ceramic
C442	MCUVIE104ZFV	Ceramic	C639	F2G1CA70003	Electrolytic
C447-451	MCUVIE104ZFV	Ceramic	C640	MCUVIE104ZFV	Ceramic
C452.453	F1HH10A004	Ceramic	C641	F2G1C100002	Electrolytic
C454	F1HC10A001	Ceramic	C642	F2G1H100001	Fluorolytic
C456	MCUVIE104ZFV	Ceramic	C643	MCUVIE104ZFV	Ceramic
C457.458	F1HH10A004	Ceramic	C644	F2G1C100002	Electrolytic
C459	MCUVIE104ZFV	Ceramic	C645	F1HH10A013	Ceramic
C460	MCUVIE104ZFV	Ceramic	C646	MCUVIE104ZFV	Ceramic
C461	ECSTIC336R	Tantalum	C647	F2G1CA70003	Electrolytic
C462	MCUVIE104ZFV	Ceramic	C648-670	MCUVIE104ZFV	Ceramic
C509	F1HH10A004	Ceramic	C671	F2G1CA70003	Electrolytic
C510	F1HH10A001	Ceramic	C672-674	MCUVIE104ZFV	Ceramic
C511	F1HH3310002	Ceramic	C675	F2G0J101002	Electrolytic
C512	MCUVIE102XBV	Ceramic	C691-693	MCUVIE104ZFV	Ceramic
C513	MCUVIE104ZFV	Ceramic	C701	MCUVIE104ZFV	Ceramic
C514	F1HH10A001	Ceramic	C702	F2G1C100002	Electrolytic
C515	MCUVIE104ZFV	Ceramic	C703	MCUVIE104ZFV	Ceramic
C516	F2G0J101002	Electrolytic	C704	F2G1C100002	Electrolytic
C517	MCUVIE1H820JCV	Ceramic	C705	MCUVIE104ZFV	Ceramic
C518	F1HH200A607	Ceramic	C706	F2G1C100002	Electrolytic
C519	EEVHP1V2R2R	Electrolytic	C707	MCUVIE104ZFV	Ceramic
C557	F1HH10A013	Ceramic	C716	F2G0J101002	Electrolytic
C558	MCUVIE104ZFV	Ceramic	C717	MCUVIE1H820JCV	Ceramic
C559	F2G1CA70003	Electrolytic	C718	F1HH200A607	Ceramic
C560	MCUVIE104ZFV	Ceramic	C719	EEVHP1V2R2R	Electrolytic
C561	F2G1C100002	Electrolytic	C731	MCUVIE104ZFV	Ceramic
C562	F2G1H100001	Electrolytic	C732	F2G1C100002	Electrolytic
C563	MCUVIE104ZFV	Ceramic	C733	MCUVIE104ZFV	Ceramic
C564	F2G1C100002	Electrolytic	C754	F2G1C100002	Electrolytic
C565	F1HH10A013	Ceramic	C755	MCUVIE104ZFV	Ceramic
C566	MCUVIE104ZFV	Ceramic	C756	F2G1C100002	Electrolytic
C567	F301CA70003	Electrolytic	C757	MCUVIE104ZFV	Ceramic
C568-570	MCUVIE104ZFV	Ceramic	C758	F1HH10A004	Ceramic
C571	F2G1CA70003	Electrolytic	C760	F1HH10A001	Ceramic
C572-574	MCUVIE104ZFV	Ceramic	C761	F1HH3310002	Ceramic
C575	F2G0J101002	Electrolytic	C762	MCUVIE102XBV	Ceramic
C576-586	MCUVIE104ZFV	Ceramic	C763	MCUVIE104ZFV	Ceramic
C607	F1HH10A013	Ceramic	C764	F1HH10A001	Ceramic
C608	MCUVIE104ZFV	Ceramic	C765	MCUVIE104ZFV	Ceramic
C609	F2G1CA70003	Electrolytic	C766	F2G0J101002	Electrolytic
C610	MCUVIE104ZFV	Ceramic	C767	MCUVIE1H820JCV	Ceramic
C611	F2G1C100002	Electrolytic	C769	EEVHP1V2R2R	Electrolytic
C612	F2G1H100001	Electrolytic	C770-771	MCUVIE104ZFV	Ceramic

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
C776-777	MCUVIE104ZFV	Ceramic	CT721	ECRJ00A011X	Trimmer
C778-780	F2G0J101002	Electrolytic	C7801.802	ECRJ00A02E11W	Trimmer
C801	EEVHB0330R	Electrolytic	C711.14	F1Z1E1520001	LC Filter
C802-808	MCUVIE104ZFV	Ceramic	L22-25	ELPJA100KF	Coil
C809	ECSTIAC336R	Tantalum	L27-30	ELPJA100KF	Coil
C810-819	F1HH10A013	Ceramic	L33-35	ELPJA100KF	Coil
C820	ECSTIAC336R	Tantalum	L38-41	ELPJA100KF	Coil
C821-828	F1HH10A013	Ceramic	L45-47	ELPJA100KF	Coil
C829-846	MCUVIE104ZFV	Ceramic	L48-52	ELPJA100KF	Coil
C847	F2G0J101002	Electrolytic	L53-57	ELPJA100KF	Coil
C848-849	MCUVIE104ZFV	Ceramic	L60-62	ELPJA100KF	Coil
C850	F2G0J101002	Electrolytic	L201-202	ELPJA100KF	Coil
C851	F1HH10A013	Ceramic	L206	ELPJA100KF	Coil
C852	F1HH10A001	Ceramic	L207-212	JOCC0000049	Coil
C853	F1HH10A013	Ceramic	L213-201	ELPJA100KF	Coil
C854	F1HH10A013	Ceramic	L351	FI1PA100KF	Coil
C857-858	F1HH10A017	Ceramic	L403-404	JOCC0000049	Coil
C859-860	MCUVIE104ZFV	Ceramic	L407-409	ELPJA100KF	Coil
C862-863	MCUVIE104ZFV	Ceramic	L410-421	JOCC0000049	Coil
C864	EEVHB0330R	Electrolytic	L553-554	JOCC0000008	Coil
C865-868	MCUVIE104ZFV	Ceramic	L555	ELPJA100KF	Coil
C869	F1HHSR00002	Ceramic	L556-603	JOCC0000008	Coil
C870	F1HH10A017	Ceramic	L604	JOCC0000008	Coil
C871	F2G0J101002	Electrolytic	L605	ELPJA100KF	Coil
C872	F1HH10A001	Ceramic	L606-653	JOCC0000008	Coil
C873	F1HHSR00002	Ceramic	L654	JOCC0000008	Coil
C874	F1HH10A017	Ceramic	L655	ELPJA100KF	Coil
C875-876	MCUVIE104ZFV	Ceramic	L656	JOCC0000008	Coil
C877	F1HH10A002	Ceramic	L702-752	G1C8R2200002	Coil
C878-879	MCUVIE104ZFV	Ceramic	L753-754	G1C8R2200002	Coil
C880	F1HH10A001	Ceramic	L801	ELPJA100KF	Coil
C881-882	MCUVIE104ZFV	Ceramic	L802-803	ELPJA100KF	Coil
C883-889	ECSTIAC336R	Tantalum	L804	ELPJA100KF	Coil
C901	EEVHB0330R	Electrolytic	L805	ELPJA100KF	Coil
C902-908	MCUVIE104ZFV	Ceramic	L808	YWF3216C181K	Coil
C909	ECSTIAC336R	Tantalum	L809-810	ELPJA100KF	Coil
C910-919	F1HH10A013	Ceramic	L812	JOCC0000008	Coil
C920	ECSTIAC336R	Tantalum	L813-814	G1C8R2200002	Coil
C921-928	F1HH10A013	Ceramic	L901	ELPJA100KF	Coil
C929-946	MCUVIE104ZFV	Ceramic	L902-904	JOCC0000008	Coil
C947	F2G0J101002	Electrolytic	L905-908	G1C8R2200002	Coil
C948-949	MCUVIE104ZFV	Ceramic	X21	H1S05B0001	Oscillator
C950	F2G0J101002	Electrolytic	X22	H0J3220005	Crystal Oscillator
C951	F1HH10A013	Ceramic	X291	YV032040A0A	Crystal Oscillator
C952	F1HH10A001	Ceramic	X402	YV032040A0A	Crystal Oscillator
C953	F1HH10A013	Ceramic	X807	HO444M0001	Crystal Oscillator
C954	F1HH10A013	Ceramic	X808	HO444M0001	Crystal Oscillator
C955-964	MCUVIE104ZFV	Ceramic	SW11	ESD16S08	Slide Switch
C966-967	MCUVIE104ZFV	Ceramic	SW21	YWSMTG101	Push Switch
C968	ECSTIAC336R	Tantalum	SW23	KO08BAA0031	Slide Switch
C969-971	MCUVIE104ZFV	Ceramic	SW24.25	YWSMTG101	Push Switch
C972-984	MCUVIE104ZFV	Ceramic	CN11	K1MM15A00008	15 pin Connector
C985	F1HH10A001	Ceramic	CN12	K1FB11D00001	11 pin Connector
C986-987	ECSTIAC336R	Tantalum	CN13	K1KA00A01140	40 pin Connector
C989	MCUVIE104ZFV	Ceramic	CN14	K1KA07A00009	7 pin Connector

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
CN15	YW6BPHS3M3	2-pin Connector	IC509	COBAZ000065	IC
CN21	K1KA0A00152	4-pin Connector	IC601.602	YWNJM25V1T1	IC
CN22	K1KA0A00146	3-pin Connector	IC603	YVTA7030P TL	IC
CN23-24	YVMA20A0130P	40-pin Connector	IC701	YVBA17014P	IC
CN27.28	K1KA03B0113	3-pin Connector	IC702	YWNJM30V1T1	IC
CN201	K1KA0A00041	64-pin Connector	IC703	COBAB000357	IC
CN202	YVMA20A0130P	4-pin Connector	IC704	COBAZ000065	IC
CN301-351	K1KB5A00082	50-pin Connector	Q101	2SD1819AHL	Transistor
CN402	K1KA0A00125	50-pin Connector	Q102.103	2SD1218AHL	Transistor
CN403	K1KA13A00067	13-pin Connector	Q104	IMZ1A	Transistor
CN404	YW6BPHS3M31B	3-pin Connector	Q105	2SD1218AHL	Transistor
B2801	L0D0EA00008	Buzzer	Q106	IMZ1A	Transistor
E1-3	YWMEP1866	Terminal	Q121	2SD1819AHL	Transistor
E-7	YWMEP1866	Terminal	Q122.123	2SD1218AHL	Transistor
TD201-203	KACA0010001	Spacer for Heat Sink	Q124	IMZ1A	Transistor
TD800-802	KACA01000013	Spacer for Heat Sink	Q125	2SD1218AHL	Transistor
TP11-14	YW32BM7RS	Test-pin	Q126	IMZ1A	Transistor
TP15-17	YWRC12125TPV	Test-pin	Q151	2SD1819AHL	Transistor
TP21-601	YWRC12125TPV	Test-pin	Q152.153	2SD1218AHL	Transistor
TP602.603	YWRC12125TPV	Test-pin	Q154	IMZ1A	Transistor
TP801.802	YWRC12125TPV	Test-pin	Q155	2SD1218AHL	Transistor
			U126	IMZ1A	Transistor
			Q171	2SD1819AHL	Transistor
			Q172.173	2SD1218AHL	Transistor
			Q174	IMZ1A	Transistor
			Q175	2SD1218AHL	Transistor
			Q176	IMZ1A	Transistor
			Q201	2SD1819AHL	Transistor
			Q202.203	2SD1218AHL	Transistor
			Q204	IMZ1A	Transistor
			Q205	2SD1218AHL	Transistor
			Q206	IMZ1A	Transistor
			Q221	2SD1819AHL	Transistor
			Q222.223	2SD1218AHL	Transistor
			Q224	IMZ1A	Transistor
			Q225	2SD1218AHL	Transistor
			Q226	IMZ1A	Transistor
			Q251	2SD1819AHL	Transistor
			Q252.253	2SD1218AHL	Transistor
			Q254	IMZ1A	Transistor
			Q255	2SD1218AHL	Transistor
			Q256	IMZ1A	Transistor
			Q271	2SD1819AHL	Transistor
			Q272.273	2SD1218AHL	Transistor
			Q274	IMZ1A	Transistor
			Q275	2SD1218AHL	Transistor
			Q276	IMZ1A	Transistor
			Q301	2SD1819AHL	Transistor
			Q302.303	2SD1218AHL	Transistor
			Q304	IMZ1A	Transistor
			Q305	2SD1218AHL	Transistor
			U306	IMZ1A	Transistor
			Q321	2SD1819AHL	Transistor
			Q322.323	2SD1218AHL	Transistor
			Q324	IMZ1A	Transistor

ANALOG BOARD

PCB2 (RTL)	8550.1KZ2A	Printed Circuit Board Assy
IC141	YW74HC04ADTE	IC
IC142	COBAR000282	IC
IC191	YW74HC04ADTE	IC
IC192	COBAR000282	IC
IC241	YW74HC04ADTE	IC
IC242	COBAR000282	IC
IC291	YW74HC04ADTE	IC
IC292	COBAR000282	IC
IC341	YW74HC04ADTE	IC
IC342	COBAR000282	IC
IC391	YW74HC04ADTE	IC
IC392	COBAR000282	IC
IC441	YW74HC04ADTE	IC
IC442	COBAR000282	IC
IC491	YW74HC04ADTE	IC
IL492	COBAR000282	IC
IC501	CO2BM49H4M2	IC
IC502	COBAR000357	IC
IC503	COBAE000224	IC

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
Q325	2SD1218AHL	Transistor	R108	ERJ3GEY1154V	Metal 150K ohms 1/16W
Q326	IMZ1A	Transistor	R109	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q351	2SD1819AHL	Transistor	R110	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
Q352.353	2SD1218AHL	Transistor	R111	ERJ3GEY1204V	Metal 300K ohms 1/16W
Q354	IMZ1A	Transistor	R112	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
Q355	2SD1218AHL	Transistor	R113	ERJ3GEY1332V	Metal 3.3K ohms 1/16W
Q356	IMZ1A	Transistor	R114	ERJ3GEY1102V	Metal 1K ohms 1/16W
Q371	2SD1819AHL	Transistor	R115	ERJ3GEY1270	Metal 27 ohms 16W
Q372.373	2SD1218AHL	Transistor	R116.117	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q374	IMZ1A	Transistor	R118.119	ERJ3GEY1102V	Metal 1K ohms 1/16W
Q375	2SD1218AHL	Transistor	R120.121	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q376	IMZ1A	Transistor	R122	YWR1200750D	Metal 75 ohms 1/16W
Q401	2SD1819AHL	Transistor	R123.124	ERJ3GEY1103V	Metal 10K ohms 1/16W
Q402.403	2SD1218AHL	Transistor	R125.126	ERJ3GEY1102V	Metal 1K ohms 1/16W
Q404	IMZ1A	Transistor	R127	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
Q405	2SD1218AHL	Transistor	R128	ERJ3GEY1154V	Metal 150K ohms 1/16W
Q406	IMZ1A	Transistor	R129	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q421	2SD1819AHL	Transistor	R130	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
Q422.423	2SD1218AHL	Transistor	R131	ERJ3GEY1304V	Metal 300K ohms 1/16W
Q424	IMZ1A	Transistor	R132	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
Q425	2SD1218AHL	Transistor	R133	ERJ3GEY1332V	Metal 3.3K ohms 1/16W
Q426	IMZ1A	Transistor	K134	ELJ4E-17102V	Aluminum 17 ohms 1/16W
Q430	2SD1819AHL	Transistor	R135	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q432.453	2SD1218AHL	Transistor	R136.137	ERJ3GEY1102V	Metal 100 ohms 1/16W
Q454	IMZ1A	Transistor	R138.139	ERJ3GEY1102V	Metal 1K ohms 1/16W
Q455	2SD1218AHL	Transistor	R140	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q456	IMZ1A	Transistor	R141	ERJ3GEY1103V	Metal 10K ohms 1/16W
Q474.476	2SD1819AHL	Transistor	R142	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q477	2SD1218AHL	Transistor	R143.144	ERJ3GEY1102V	Metal 2.2K ohms 1/16W
Q472.473	2SD1218AHL	Transistor	R145	ERJ3GEY1102V	Metal 100 ohms 1/16W
Q475	2SD1218AHL	Transistor	R146.147	ERJ3GEY1202V	Metal 100 ohms 1/16W
Q501.512	YWR12004500L	Inductor	R151	ERJ3GEY1101V	Metal 100 ohms 1/16W
Q522.611	2SD1819AHL	Transistor	R152	YWR1200750D	Metal 75 ohms 1/16W
Q612.613	2SD1819AHL	Transistor	R153.154	ERJ3GEY1102V	Metal 10K ohms 1/16W
Q621.623	2SD1819AHL	Transistor	R155.156	ERJ3GEY1103V	Metal 1K ohms 1/16W
Q631.633	2SD1819AHL	Transistor	R157	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
Q701.704	2SD1218AHL	Transistor	R158	ERJ3GEY1154V	Metal 150K ohms 1/16W
Q705	2SD12300L	Transistor	R159	ERJ3GEY1101V	Metal 100 ohms 1/16W
D101.121	DA204K-146	Diode	R160	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
D151.171	DA204K-146	Diode	R161	ERJ3GEY1304V	Metal 300K ohms 1/16W
D201.221	DA204K-146	Diode	R162	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
D251.271	DA204K-146	Diode	R163	ERJ3GEY1332V	Metal 3.3K ohms 1/16W
D301.321	DA204K-146	Diode	R164	ERJ3GEY1102V	Metal 1K ohms 1/16W
D351.371	DA204K-146	Diode	R165	ERJ3GEY1270	Metal 27 ohms 1/16W
D401.421	DA204K-146	Diode	R166.167	ERJ3GEY1101V	Metal 100 ohms 1/16W
D451.471	DA204K-146	Diode	R168.169	ERJ3GEY1102V	Metal 1K ohms 1/16W
D700.702	MA3152A0L	Diode	R170.171	ERJ3GEY1101V	Metal 100 ohms 1/16W
D703	MA32090LL	Diode	R172	YWR1200750D	Metal 75 ohms 1/16W
D710	THYRISTOR 2N2218	Thyristor	R173.174	ERJ3GEY1102V	Metal 10K ohms 1/16W
R11	ERJ4Y1102	Metal	R175.176	ERJ3GEY1102V	Metal 1K ohms 1/16W
R101	ERJ3GEY1101V	Metal	R177	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
R102	THYRISTOR 2N2218	Metal	K178	ELJ4E-37140V	Aluminum 37 ohms 1/16W
R103.104	ERJ3GEY1102V	Metal	R179	ERJ3GEY1101V	Metal 100 ohms 1/16W
R105	ERJ3GEY1103V	Metal	R180	ERJ3GEY1222V	Metal 2.2K ohms 1/16W
R107	ERJ3GEY1222V	Metal	R181	ERJ3GEY1304V	Metal 300K ohms 1/16W

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R182	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R260	ERJGEYJ22V	Metal 2.2k ohms 1/6W
R183	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W	R261	ERJGEYJ304V	Metal 300k ohms 1/6W
R184	ERJGEYJ10V	Metal 1k ohms 1/6W	R262	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R185	ERJGEYJ27V	Metal 27 ohms 1/6W	R263	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W
R186,187	ERJGEYJ10V	Metal 10k ohms 1/6W	R264	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R198,189	ERJGEYJ10V	Metal 1k ohms 1/6W	R265	ERJGEYJ27V	Metal 27 ohms 1/6W
R190	ERJGEYJ10V	Metal 100 ohms 1/6W	R266,267	ERJGEYJ10V	Metal 100 ohms 1/6W
R191	ERJGEYJ10V	Metal 10k ohms 1/6W	R268,269	ERJGEYJ10V	Metal 10k ohms 1/6W
R192	ERJGEYJ10V	Metal 100 ohms 1/6W	R270,271	ERJGEYJ10V	Metal 100 ohms 1/6W
R193,194	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R272	YWR1200750D	Metal 75 ohms 1/6W
R195	ERJGEYJ10V	Metal 100 ohms 1/6W	R273,274	ERJGEYJ10V	Metal 10k ohms 1/6W
R196,197	ERJGEYJ10V	Metal 2.2 ohms 1/6W	R275,276	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R201	ERJGEYJ154V	Metal 75 ohms 1/6W	R277	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R202	YWR1200750D	Metal 75 ohms 1/6W	R278	CRJCEYJ154V	Metal 150k ohms 1/6W
R203,204	ERJGEYJ10V	Metal 10k ohms 1/6W	R279	ERJGEYJ10V	Metal 100 ohms 1/6W
R205,206	FR13GFY102V	Metal 1k ohms 1/6W	R280	FR13GFY127V	Metal 27k ohms 1/6W
R207	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R281	ERJGEYJ304V	Metal 300k ohms 1/6W
R208	ERJGEYJ154V	Metal 150k ohms 1/6W	R282	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R209	ERJGEYJ10V	Metal 100 ohms 1/6W	R283	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W
R210	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R284	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R211	ERJGEYJ304V	Metal 300k ohms 1/6W	R285	ERJGEYJ27V	Metal 27 ohms 1/6W
R212	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R286,287	ERJGEYJ10V	Metal 100 ohms 1/6W
R213	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W	R288,289	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R214	ERJGEYJ10V	Metal 100 ohms 1/6W	R290	ERJGEYJ10V	Metal 2.2k ohms 1/6W
R215	ERJGEYJ27V	Metal 27 ohms 1/6W	R291	ERJGEYJ10V	Metal 10k ohms 1/6W
R216,217	ERJGEYJ10V	Metal 100 ohms 1/6W	R292	ERJGEYJ10V	Metal 100 ohms 1/6W
R218,219	ERJGEYJ10V	Metal 1k ohms 1/6W	R293,294	ERJGEYJ28V	Metal 2.2 ohms 1/6W
R220,221	ERJGEYJ10V	Metal 100 ohms 1/6W	R295	ERJGEYJ10V	Metal 100 ohms 1/6W
R222	YWR1200750D	Metal 75 ohms 1/6W	R296,297	ERJGEYJ28V	Metal 2.2 ohms 1/6W
R223,224	ERJGEYJ10V	Metal 100 ohms 1/6W	R301	ERJGEYJ10V	Metal 100 ohms 1/6W
R225,226	ERJGEYJ10V	Metal 1k ohms 1/6W	R302	YWR1200750D	Metal 75 ohms 1/6W
R227	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R303,304	ERJGEYJ10V	Metal 10k ohms 1/6W
R228	ERJGEYJ154V	Metal 150k ohms 1/6W	R305,306	ERJGEYJ10V	Metal 1k ohms 1/6W
R229	ERJGEYJ10V	Metal 100 ohms 1/6W	R307	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R230	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R308	ERJGEYJ154V	Metal 150k ohms 1/6W
R231	ERJGEYJ304V	Metal 300k ohms 1/6W	R309	ERJGEYJ10V	Metal 100 ohms 1/6W
R232	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R310	ERJGEYJ22V	Metal 2.2k ohms 1/6W
R233	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W	R311	ERJGEYJ304V	Metal 300k ohms 1/6W
R234	ERJGEYJ10V	Metal 2.2k ohms 1/6W	R312	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R235	ERJGEYJ27V	Metal 27 ohms 1/6W	R313	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W
R236,237	ERJGEYJ10V	Metal 100 ohms 1/6W	R314	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R238,239	ERJGEYJ10V	Metal 1k ohms 1/6W	R315	ERJGEYJ27V	Metal 27 ohms 1/6W
R240	ERJGEYJ10V	Metal 100 ohms 1/6W	R316,317	ERJGEYJ10V	Metal 100 ohms 1/6W
R241	ERJGEYJ10V	Metal 10k ohms 1/6W	R318,319	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R242	ERJGEYJ10V	Metal 100 ohms 1/6W	R320,321	ERJGEYJ10V	Metal 100 ohms 1/6W
R243,244	FR13GFY102V	Metal 27 ohms 1/6W	R322	YWR1200750D	Metal 75 ohms 1/6W
R245	ERJGEYJ10V	Metal 100 ohms 1/6W	R323,324	ERJGEYJ22V	Metal 2.2k ohms 1/6W
R246,247	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R325,326	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R248	ERJGEYJ10V	Metal 100 ohms 1/6W	R327	ERJGEYJ10V	Metal 2.2k ohms 1/6W
R252	YWR1200750D	Metal 75 ohms 1/6W	R328	ERJGEYJ154V	Metal 150k ohms 1/6W
R253,254	ERJGEYJ10V	Metal 100 ohms 1/6W	R329	ERJGEYJ10V	Metal 100 ohms 1/6W
R255,256	ERJGEYJ10V	Metal 1k ohms 1/6W	R330	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R257	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R331	ERJGEYJ304V	Metal 300k ohms 1/6W
R258	ERJGEYJ154V	Metal 150k ohms 1/6W	R332	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R259	ERJGEYJ10V	Metal 100 ohms 1/6W	R333	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W

- 57 -

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R486,487	ERJGEYJ10V	Metal 100 ohms 1/6W	R724	ERJGEYJ104V	Metal 100k ohms 1/6W
R488,489	ERJGEYJ10V	Metal 1k ohms 1/6W	R725	ERJGEYJ389V	Metal 3.9k ohms 1/6W
R490	ERJGEYJ10V	Metal 100 ohms 1/6W	R726	ERJGEYJ47ZV	Metal 4.7k ohms 1/6W
R491	ERJGEYJ10V	Metal 10k ohms 1/6W	R727	ERJGEYJ22V	Metal 2.2k ohms 1/6W
R492	ERJGEYJ10V	Metal 100 ohms 1/6W	R728	ERJGEYJ104V	Metal 100k ohms 1/6W
R493,494	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R731	ERJGEYJ812V	Metal 5.1k ohms 1/6W
R495	ERJGEYJ10V	Metal 100 ohms 1/6W	R732	ERJGEYJ22V	Metal 2.2k ohms 1/6W
R496,497	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R733	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W
R501,524	ERJGEYJ22V	Metal 1k ohms 1/6W	R735,738	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R553	ERJGEYJ22V	Metal 220 ohms 1/6W	R739	ERJGEYJ395	Metal 39k ohms 1/6W
R555	ERJGEYJ10V	Metal 1k ohms 1/6W	R740,741	ERJGEYJ103V	Metal 10k ohms 1/6W
R556,561	ERJGEYJ22V	Metal 2.2k ohms 1/6W	R742	ERJGEYJ103V	Metal 3.3k ohms 1/6W
R511	ERJGEYJ10V	Metal 1k ohms 1/6W	R743	ERJGEYJ104V	Metal 100k ohms 1/6W
R512	YWR0814P10D	Metal 1k ohms 1/6W	R745,747	ERJGEYJ22ZV	Metal 2.2k ohms 1/6W
R513	ERJGEYJ75V	Metal 750 ohms 1/6W	V0611,621	EVMD5W30B13	Semiconductor 1k ohms
R514	YWR0814P10D	Metal 1k ohms 1/6W	V0613	EVMD5W30B13	Semiconductor 1k ohms
R515	ERJGEYJ132V	Metal 1.3k ohms 1/6W	C13-15	F2H0Z210001	Electrolytic 220 µF 6.3V
R516,617	ERJGEYJ10V	Metal 10k ohms 1/6W	C101	EEVHP0470P	Electrolytic 47 µF 6.3V
R518	ERJGEYJ10V	Metal 1k ohms 1/6W	C102	MCUVIE104ZFV	Ceramic 0.1 µF
R519	ERJGEYJ10V	Metal 100 ohms 1/6W	C103	F1HH101A004	Ceramic 100 pF
R521	ERJGEYJ10V	Metal 1k ohms 1/6W	C104	F1HA105A004	Ceramic 1 µF
R522	YWR0814P10D	Metal 1k ohms 1/6W	C105	F1HH103A050	Ceramic 0.1 µF
R523	ERJGEYJ75V	Metal 750 ohms 1/6W	C106	F1HC104A001	Ceramic 0.1 µF
R524	YWR0814P10D	Metal 1k ohms 1/6W	C107	F2G01010002	Electrolytic 100 µF 6.3V
R525	ERJGEYJ132V	Metal 1.3k ohms 1/6W	C121	EEVHP0470P	Electrolytic 47 µF 6.3V
R526,627	ERJGEYJ10V	Metal 10k ohms 1/6W	C122	MCUVIE104ZFV	Ceramic 0.1 µF
R528	FR13GFY102V	Metal 27 ohms 1/6W	C123	F1HH103A050	Ceramic 0.1 µF
R529	ERJGEYJ10V	Metal 100 ohms 1/6W	C124	F1HA105A004	Ceramic 1 µF
R531	ERJGEYJ10V	Metal 10k ohms 1/6W	C125	F1HH103A050	Ceramic 0.1 µF
R532	YWR0814P10D	Metal 1k ohms 1/6W	C126	F1HC104A001	Ceramic 0.1 µF
R533	ERJGEYJ75V	Metal 750 ohms 1/6W	C127	F2G01010002	Electrolytic 100 µF 6.3V
R534	YWR0814P10D	Metal 1k ohms 1/6W	C142,143	MCUVIE104ZFV	Ceramic 0.1 µF
R535	ERJGEYJ142V	Metal 3.3k ohms 1/6W	C144	EEVHP0470P	Electrolytic 47 µF 6.3V
R536,637	ERJGEYJ10V	Metal 10k ohms 1/6W	C152	MCUVIE104ZFV	Ceramic 0.1 µF
R538	ERJGEYJ10V	Metal 1k ohms 1/6W	C153	F1HH101A004	Ceramic 100 pF
R539,640	ERJGEYJ10V	Metal 100 ohms 1/6W	C154	F1HA105A004	Ceramic 1 µF
R542,644	ERJGEYJ10V	Metal 100 ohms 1/6W	C155	F1HH103A050	Ceramic 0.1 µF
R701	ERJGEYJ28V	Metal 2.2k ohms 1/6W	C156	F1HC104A001	Ceramic 0.1 µF
R702	ERJGEYJ080V	Metal 80 ohms 1/6W	C157	F2G01010002	Electrolytic 100 µF 6.3V
R703	ERJGEYJ104V	Metal 100k ohms 1/6W	C171	EEVHP0470P	Electrolytic 47 µF 6.3V
R704	MCUVIE104ZFV	Metal 15k ohms 1/6W	C172	MCUVIE104ZFV	Ceramic 0.1 µF
R705	ERJGEYJ53V	Metal 53k ohms 1/6W	C173	F1HH103A050	Ceramic 0.1 µF
R706	ERJGEYJ27V	Metal 27k ohms 1/6W	C174	F1HA105A004	Ceramic 1 µF
R707	CRJGEYJ513V	Metal 51k ohms 1/6W	C175	F1HH103A050	Ceramic 0.1 µF
R708	ERJGEYJ104V	Metal 100k ohms 1/6W	C176	F1HC104A001	Ceramic 0.1 µF
R709	ERJGEYJ389V	Metal 3.9k ohms 1/6W	C177	F2G01010002	Electrolytic 100 µF 6.3V
R710	ERJGEYJ22V	Metal 2.2k ohms 1/6W	C192,193	MCUVIE104ZFV	Ceramic 0.1 µF
R711	ERJGEYJ33ZV	Metal 3.3k ohms 1/6W	C201	EEVHP0470P	Electrolytic 47 µF 6.3V
R713	ERJGEYJ47ZV	Metal 4.7k ohms 1/6W	C202	MCUVIE104ZFV	Ceramic 0.1 µF
R714	ERJGEYJ22V	Metal 2.2k ohms 1/6W	C203	F1HH101A004	Ceramic 100 pF
R715	ERJGEYJ812V	Metal 5.1k ohms 1/6W	C204	F1HA105A004	Ceramic 1 µF
R716	CRJGEYJ22ZV	Metal 2.2k ohms 1/6W	C205	F1HH103A050	Ceramic 0.1 µF
R717	ERJGEYJ22V	Metal 2.2k ohms 1/6W	C206	F1HC104A001	Ceramic 0.1 µF
R722	ERJGEYJ10V	Metal 10k ohms 1/6W	C207	F2G01010002	Electrolytic 100 µF 6.3V
R723	ERJGEYJ32V	Metal 32k ohms 1/6W	C208	EEVHP0470P	Electrolytic 47 µF 6.3V

- 59 -

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R334	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R412	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R335	ERJGEYJ27V	Metal 27 ohms 1/6W	R413	ERJGEYJ33ZV	Metal 3.3K ohms 1/6W
R336,337	ERJGEYJ10V	Metal 100 ohms 1/6W	R414	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R338,339	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R415	ERJGEYJ27V	Metal 27 ohms 1/6W
R340	ERJGEYJ10V	Metal 100 ohms 1/6W	R416,417	ERJGEYJ10V	Metal 100 ohms 1/6W
R341	ERJGEYJ10V	Metal 10K ohms 1/6W	R418,419	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R342	ERJGEYJ10V	Metal 100 ohms 1/6W	R420,421	ERJGEYJ10V	Metal 100 ohms 1/6W
R343,344	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R422	YWR1200750D	Metal 75 ohms 1/6W
R345	ERJGEYJ10V	Metal 100 ohms 1/6W	R423,424	ERJGEYJ10V	Metal 10K ohms 1/6W
R346,347	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R425,426	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R351	ERJGEYJ10V	Metal 100 ohms 1/6W	R427	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R352	YWR1200750D	Metal 75 ohms 1/6W	R428	ERJGEYJ154V	Metal 150K ohms 1/6W
R353,354	ERJGEYJ10V	Metal 10K ohms 1/6W	R429	ERJGEYJ10V	Metal 100 ohms 1/6W
R355,356	ERJGEYJ10V	Metal 1K ohms 1/6W	R430	CRJGEYJ28ZV	Metal 2.2K ohms 1/6W
R357	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R431	ERJGEYJ304V	Metal 300K ohms 1/6W
R358	FR13GFY154V	Metal 150K ohms 1/6W	R432	FR13GFY127V	Metal 27K ohms 1/6W
R359	ERJGEYJ10V	Metal 100 ohms 1/6W	R433	ERJGEYJ33ZV	Metal 3.3K ohms 1/6W
R360	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R434	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R361	ERJGEYJ304V	Metal 300K ohms 1/6W	R435	ERJGEYJ27V	Metal 27 ohms 1/6W
R362	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R436,437	ERJGEYJ10V	Metal 100 ohms 1/6W
R363	ERJGEYJ33ZV	Metal 3.3K ohms 1/6W	R438,439	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R364	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R440	ERJGEYJ10V	Metal 100 ohms 1/6W
R365	ERJGEYJ27V	Metal 27 ohms 1/6W	R441	ERJGEYJ10V	Metal 10K ohms 1/6W
R366,367	ERJGEYJ10V	Metal 100 ohms 1/6W	R442	ERJGEYJ10V	Metal 100 ohms 1/6W
R368,369	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R443,444	ERJGEYJ28V	Metal 2.2 ohms 1/6W
R370,371	ERJGEYJ10V	Metal 100 ohms 1/6W	R445	ERJGEYJ10V	Metal 100 ohms 1/6W
R372	YWR1200750D	Metal 75 ohms 1/6W	R446,447	ERJGEYJ28V	Metal 2.2 ohms 1/6W
R373,374	ERJGEYJ10V	Metal 10K ohms 1/6W	R448	ERJGEYJ10V	Metal 10K ohms 1/6W
R375,376	ERJGEYJ28V	Metal 2.2 ohms 1/6W	R449	YWR1200750D	Metal 75 ohms 1/6W
R377	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R453,454	ERJGEYJ10V	Metal 10K ohms 1/6W
R378	ERJGEYJ154V	Metal 150K ohms 1/6W	R455,456	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R379	ERJGEYJ10V	Metal 100 ohms 1/6W	R457	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R380	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R458	CRJGEYJ154V	Metal 150K ohms 1/6W
R381	ERJGEYJ304V	Metal 300K ohms 1/6W	R459	ERJGEYJ10V	Metal 100 ohms 1/6W
R382	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R460	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R383	ERJGEYJ33ZV	Metal 3.3K ohms 1/6W	R461	ERJGEYJ304V	Metal 300K ohms 1/6W
R384	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R462	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R385	ERJGEYJ27V	Metal 27 ohms 1/6W	R463	ERJGEYJ33ZV	Metal 3.3K ohms 1/6W
R386,387	ERJGEYJ10V	Metal 100 ohms 1/6W	R464	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R388,389	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R465	ERJGEYJ27V	Metal 27 ohms 1/6W
R390	ERJGEYJ10V	Metal 100 ohms 1/6W	R466,467	ERJGEYJ10V	Metal 100 ohms 1/6W
R391	ERJGEYJ10V	Metal 10K ohms 1/6W	R468,469	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R392	ERJGEYJ10V	Metal 100 ohms 1/6W	R470,471	ERJGEYJ10V	Metal 10K ohms 1/6W
R393,394	CRJGEYJ154V	Metal 2.2 ohms 1/6W	R472	YWR1200750D	Metal 75 ohms 1/6W
R395	ERJGEYJ10V	Metal 100 ohms 1/6W	R473,474	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R396,397	FR13GFY127V	Metal 27 ohms 1/6W	R475,476	FR13GFY10ZV	Metal 1K ohms 1/6W
R401	ERJGEYJ10V	Metal 100 ohms 1/6W	R477	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R403,404	YWR1200750D	Metal 75 ohms 1/6W	R478	ERJGEYJ154V	Metal 150K ohms 1/6W
R405,406	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R479	ERJGEYJ10V	Metal 100 ohms 1/6W
	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R480	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R407	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R481	ERJGEYJ304V	Metal 300K ohms 1/6W
R408	ERJGEYJ10ZV	Metal 1K ohms 1/6W	R482	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W
R409	ERJGEYJ10V	Metal 100 ohms 1/6W	R483	ERJGEYJ33ZV	Metal 3.3K ohms 1/6W
R410	ERJGEYJ22ZV	Metal 2.2K ohms 1/6W	R484	ERJGEYJ10ZV	Metal 1K ohms 1/6W
R411	ERJGEYJ10V	Metal 100 ohms 1/6W	R485	ERJGEYJ27V	Metal 27 ohms 1/6W

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
C637	F1H0105A001	Ceramic	TP11-14	YW32BM/R5	Test-pin Mounting Angle
C638,640	F2G01010002	Electrolytic	M82	V25A000A3	
C641	MCUVIE1042FV	Ceramic			
C701	F2G01010002	Electrolytic			
	F2G1C1010004	Electrolytic			
C702	F1H1E2240004	Ceramic			
C703	MCUVIE1042FV	Ceramic			
C704	F2G1C1000002	Electrolytic			
C705	F1H1A105A004	Ceramic			
C706,707	MCUVIE1042FV	Ceramic			
C708	F2G01010002	Electrolytic			
C709	F2G1C1000002	Electrolytic			
C711	F1H1A105A004	Ceramic			
C712	MCUVIE1042FV	Ceramic			
C713	F2G01010002	Electrolytic			
C714-716	MCUVIE1042FV	Ceramic			
C717	F2G1C1000002	Electrolytic			
L101,121	G1C082J00002	Coil			
L151,171	G1C082J00002	Coil			
L172	YWPC10220K	Coil			
L173,174	G2K00000349	Coil			
L201,221	G1C082J00002	Coil			
L251,271	G1C082J00002	Coil			
L301,321	G1C082J00002	Coil			
L361,371	G1C082J00002	Coil			
L401,421	G1C082J00002	Coil			
L451,471	G1C082J00002	Coil			
L501,504	G1C082J00002	Coil			
L611	ELJFC320K	Coil			
L612	ELJFC320K	Coil			
L613	G1C082J00002	Coil			
L621	ELJFC320K	Coil			
L622	ELJFC320K	Coil			
L631	ELJFC320K	Coil			
L632	ELJFC320K	Coil			
L633,701	G1C082J00002	Coil			
L702,703	G1C082J00002	Coil			
CN11	K1M15A00008	15-pin Connector			
CN13	K1A4A000140	4-pin Connector			
CN14	YWL04T	4-pin Connector			
CN15	K1A6T000009	7-pin Connector			
CN16	K1A6A000080	4-pin Connector			
CN17	YWB4P-VH	BNC Connector			
CN19,123	K10B0C00003	BNC Connector			
CN19,123	K10B0C00003	BNC Connector			
CN20,171	K10B0C00003	BNC Connector			
CN21,271	K10B0C00003	BNC Connector			
CN301,321	K10B0C00003	BNC Connector			
CN351,371	K10B0C00003	BNC Connector			
CN401,421	K10B0C00003	BNC Connector			
CN451,471	K10B0C00003	BNC Connector			
CN501,562	K1M15A00012	52-pin Connector			
CN701	YWB173019-2	2-pin Connector			
SF13.14	K5H500A0001	Current Fuse			
E1.7	YWMPE1866	Terminal			

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
C136	MCUVIE1042FV	Ceramic	C214	EEVH01C100R	Electrolytic
C137	F1H1H10A013	Ceramic	C315	MCUVIE1042FV	Ceramic
C141,149	MCUVIE1042FV	Ceramic	C316	F1H1952A013	Ceramic
C147	F1H1H10A013	Ceramic	C317	F1H1E1530002	Ceramic
C151,156	MCUVIE1042FV	Ceramic	C318	F1H1H82A013	Ceramic
C157	F1H1H10A013	Ceramic	C319	F1H1H82A013	Ceramic
C161	MCUVIE1042FV	Ceramic	C320	CM402	Ceramic
C162	F1H1H10A013	Ceramic	C321	F1H1H82A013	Ceramic
C166	MCUVIE1042FV	Ceramic	C322	MCUVIE1042FV	Ceramic
C167	F1H1H10A013	Ceramic	C323	MCUVIE1042FV	Ceramic
C171	MCUVIE1042FV	Ceramic	C324	F1H1H102A004	Ceramic
C172	F1H1H10A013	Ceramic	C325	F1H1H105A001	Ceramic
C176	MCUVIE1042FV	Ceramic	C326,327	F1H1H105A001	Ceramic
C177	F1H1H10A013	Ceramic	C328	CEVIB0J220R	Electrolytic
C181	MCUVIE1042FV	Ceramic	C329	EEVH0101P	Electrolytic
C182	F1H1H10A013	Ceramic	C330	MCUVIE1042FV	Ceramic
C186	MCUVIE1042FV	Ceramic	C331	EEVH010221P	Electrolytic
C187	F1H1H10A013	Ceramic	C332	EEVH010220R	Electrolytic
C191	MCUVIE1042FV	Ceramic	C333	EEVH0101P	Electrolytic
C192	F1H1H10A013	Ceramic	C334	MCUVIE1042FV	Ceramic
C196	MCUVIE1042FV	Ceramic	C335	EEVH010221P	Electrolytic
C199	F1H1H105A013	Ceramic	C401-407	F1C1E1520001	Ceramic
C198,201	MCUVIE1042FV	Ceramic	C410,411	F1H1H221A004	Ceramic
C202	F1H1H10A013	Ceramic	C412	EEVH0101P	Electrolytic
C206	MCUVIE1042FV	Ceramic	C413	MCUVIE1042FV	Ceramic
C207	F1H1H10A013	Ceramic	C414	F1H1H10A013	Ceramic
C211	MCUVIE1042FV	Ceramic	C415	F1H1H105A007	Ceramic
C212	F1H1H10A013	Ceramic	C416	G1C15100001	Coil
C216	MCUVIE1042FV	Ceramic	C417	G1C10100002	Coil
C217	F1H1H10A013	Ceramic	C418	G1C10100002	Coil
C221	MCUVIE1042FV	Ceramic	C419	G1C10100002	Coil
C222	F1H1H10A013	Ceramic	C420	G1C10100002	Coil
C223	MCUVIE1042FV	Ceramic	C421	G1C10100002	Coil
C227	F1H1H10A013	Ceramic	C422	G1C10100002	Coil
C228	MCUVIE1042FV	Ceramic	C423	G1C10100002	Coil
C231,236	MCUVIE1042FV	Ceramic	C424	G1C10100002	Coil
C237	F1H1H10A013	Ceramic	C425	G1C10100002	Coil
C242	MCUVIE1042FV	Ceramic	C426	G1C10100002	Coil
C246	MCUVIE1042FV	Ceramic	C427	G1C10100002	Coil
C247	F1H1H10A013	Ceramic	C428	G1C10100002	Coil
C251	MCUVIE1042FV	Ceramic	C429	G1C10100002	Coil
C252	F1H1H10A013	Ceramic	C430	G1C10100002	Coil
C256,261	MCUVIE1042FV	Ceramic	C431	G1C10100002	Coil
C266,271	MCUVIE1042FV	Ceramic	C432	G1C10100002	Coil
C276	MCUVIE1042FV	Ceramic	C433	G1C10100002	Coil
C277	F1H1H10A013	Ceramic	C434	G1C10100002	Coil
C281,286	MCUVIE1042FV	Ceramic	C435	G1C10100002	Coil
C281,286	MCUVIE1042FV	Ceramic	C436	G1C10100002	Coil
C286,301	MCUVIE1042FV	Ceramic	C437	G1C10100002	Coil
C302	F1H1A105A004	Ceramic	C438	G1C10100002	Coil
C303	EEVH0101P	Electrolytic	C439	G1C10100002	Coil
C304-309	MCUVIE1042FV	Ceramic	C440	G1C10100002	Coil
C310,311	F1H0105A001	Ceramic	C441	G1C10100002	Coil
C312	F1H1A105A004	Ceramic	C442	G1C10100002	Coil
C313	EEVH0101P	Electrolytic	C443	G1C10100002	Coil

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R106	ERJ3GEYJ101V	Metal	R246	ERJ3GEYJ101V	Metal
R107	ERJ3GEYJ332V	Metal	R247	ERJ3GEYJ332V	Metal
R111	ERJ3GEYJ101V	Metal	R251	ERJ3GEYJ101V	Metal
R112	ERJ3GEYJ332V	Metal	R252	ERJ3GEYJ332V	Metal
R116	ERJ3GEYJ101V	Metal	R256,261	ERJ3GEY0800	Metal
R117	ERJ3GEYJ332V	Metal	R266,271	ERJ3GEY0800	Metal
R121	ERJ3GEYJ101V	Metal	R276	ERJ3GEYJ101V	Metal
R122	ERJ3GEYJ332V	Metal	R277	ERJ3GEYJ332V	Metal
R126	ERJ3GEYJ101V	Metal	R281,286	ERJ3GEY0800	Metal
R127	ERJ3GEYJ332V	Metal	R291,296	ERJ3GEY0800	Metal
R131	ERJ3GEYJ101V	Metal	R298	ERJ3GEY0800	Metal
R132	ERJ3GEYJ332V	Metal	R301,302	ERJ3GEYJ220V	Metal
R136	ERJ3GEYJ101V	Metal	R303	ERJ3GEYJ103V	Metal
R137	ERJ3GEYJ332V	Metal	R304	ERJ3GEYJ444V	Metal
R141	ERJ3GEY0800	Metal	R305	ERJ3GEYJ383V	Metal
R146	FR13GFY101V	Metal	R307	FR13GFY0800	Metal
R147	ERJ3GEYJ332V	Metal	R309	ERJ3GEYJ103V	Metal
R151	ERJ3GEYJ101V	Metal	R310	ERJ3GEYJ104V	Metal
R155	ERJ3GEYJ101V	Carbon	R311	ERJ3GEYJ103V	Metal
R156	ERJ3GEYJ101V	Metal	R312	ERJ3GEYJ104V	Metal
R157	ERJ3GEYJ332V	Metal	R313	ERJ3GEYJ321V	Metal
R158	ERJ3GEYJ103V	Metal	R314	ERJ3GEYJ103V	Metal
R161	ERJ3GEYJ332V	Metal	R315	ERJ3GEYJ237V	Metal
R162	ERJ3GEYJ332V	Metal	R316	ERJ3GEYJ237V	Metal
R166	ERJ3GEYJ101V	Metal	R317,320	ERJ3GEYJ103V	Metal
R167	ERJ3GEYJ332V	Metal	R321	ERJ3GEYJ101V	Metal
R171	ERJ3GEYJ101V	Metal	R322	ERJ3GEYJ230V	Metal
R172	ERJ3GEYJ332V	Metal	R323,328	ERJ3GEYJ103V	Metal
R176	ERJ3GEYJ101V	Metal	R329,330	ERJ3GEYJ105V	Metal
R177	ERJ3GEYJ332V	Metal	R331	ERJ3GEYJ362V	Metal
R181	ERJ3GEYJ101V	Metal	R332	ERJ3GEYJ750V	Metal
R182	ERJ3GEYJ332V	Metal	R351-353	ERJ3GEYJ101V	Metal
R186	ERJ3GEYJ101V	Metal	R355	ERJ3GEYJ103V	Metal
R187	ERJ3GEYJ332V	Metal	R356	ERJ3GEYJ222V	Metal
R191	ERJ3GEYJ101V	Metal	R357	ERJ3GEY0800	Metal
R192	ERJ3GEYJ332V	Metal	R358-360	ERJ3GEYJ103V	Metal
R196	ERJ3GEYJ101V	Metal	R401,402	ERJ3GEYJ220V	Metal
R197	ERJ3GEYJ332V	Metal	R403,404	ERJ3GEYJ800V	Metal
R198,201	ERJ3GEYJ101V	Metal	R405,406	ERJ3GEYJ103V	Metal
R202	ERJ3GEYJ332V	Metal	R407,408	ERJ3GEYJ222V	Metal
R206	ERJ3GEYJ101V	Metal	R409	ERJ3GEYJ103V	Metal
R207	ERJ3GEYJ332V	Metal	R401	MCUVIE1042FV	Ceramic
R211	ERJ3GEYJ101V	Metal	C102	F1H1H10A013	Ceramic
R212	ERJ3GEYJ332V	Metal	C106	MCUVIE1042FV	Ceramic
R216	ERJ3GEYJ101V	Metal	C107	F1H1H10A013	Ceramic
R217	FR13GFY103V	Metal	C111	MCUVIE1042FV	Ceramic
R221	ERJ3GEYJ332V	Metal	C112	F1H1H10A013	Ceramic
R222	ERJ3GEYJ332V	Metal	C116	MCUVIE1042FV	Ceramic
R226	ERJ3GEYJ101V	Metal	C117	F1H1H10A013	Ceramic
R227	ERJ3GEYJ332V	Metal	C121	MCUVIE1042FV	Ceramic
R231	ERJ3GEY0800	Metal	C122	F1H1H10A013	Ceramic
R236	ERJ3GEYJ101V	Metal	C126	MCUVIE1042FV	Ceramic
R237	ERJ3GEYJ332V	Metal	C127	F1H1H10A013	Ceramic
R241	ERJ3GEYJ101V	Metal	C131	MCUVIE1042FV	Ceramic
R242	ERJ3GEYJ332V	Metal	C132	F1H1H10A013	Ceramic

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
CN12	K1F1B1D0001	1-pin Connector	R018	ERJ3GEYJ151V	Metal
CN101,201	YWB255A3AG	D Sub Connector	R019	ERJ3GEYJ152V	Metal
CN301,302	YWB11952A013	Modular Jack	R020	ERJ3GEYJ151V	Metal
CN303	K10B0C00003	BNC Connector	R021	ERJ3GEYJ152V	Metal
CN304	JEV91A3G13	9-pin Connector	R022-829	ERJ3GEYJ123V	Metal
CN305	K2H040B0015	Jack	R030	ERJ3GEYJ151V	Metal
CN306	K1E150B01000	50-pin Connector	R031	ERJ3GEYJ152V	Metal
E1.2	YWMPE1866	Terminal	R032	ERJ3GEYJ151V	Metal
TP301	YWBCT2125TPV	Test-pin	R033	ERJ3GEYJ152V	Metal
			R034	ERJ3GEYJ151V	Metal
			R035	ERJ3GEYJ152V	Metal
			R036	ERJ3GEYJ151V	Metal
			R037	ERJ3GEYJ152V	Metal
			R038	ERJ3GEYJ151V	Metal
			R039	ERJ3GEYJ152V	Metal
			R040	ERJ3GEYJ151V	Metal
			R041	ERJ3GEYJ152V	Metal
			R042	ERJ3GEYJ151V	Metal
			R043	ERJ3GEYJ152V	Metal
			R044	ERJ3GEYJ151V	Metal
			R045	ERJ3GEYJ152V	Metal
			R046	ERJ3GEYJ151V	Metal
			R047	ERJ3GEYJ152V	Metal
			R048	ERJ3GEYJ151V	Metal
			R049	ERJ3GEYJ152V	Metal
			R050	ERJ3GEYJ151V	Metal
			R051	ERJ3GEYJ152V	Metal
			R052-855	ERJ3GEYJ123V	Metal
			R056	ERJ3GEYJ151V	Metal
			R057,858	ERJ3GEYJ121V	Metal
			R059-864	ERJ3GEYJ102V	Metal
			R065-870	ERJ3GEYJ103V	Metal
			R071-874	ERJ3GEYJ151V	Metal
			R072,873	ERJ3GEYJ151V	Metal
			R074	ERJ3GEYJ103V	Metal
			R081	F2G04700002	Electro

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
LED BOARD					
PCBS (RTL)	J860KIC24A	Printed Circuit Board Assy	C6	EC052GB47EB	Electrolytic 470 µF 400V
Q12.1	RCYDGT00091	Transistor	C7	MCU01E104KBN	Ceramic 0.1 µF
D11	YW5R3R29MGT	LED	C8	EC0E64738F	Plastic 0.047 µF 630V
R11.13	YW5R3R29D10T	LED	C9	F1JC11050002	Ceramic 1 µF
	ERJAGEYJ2TV		C10	EE18E1A101	Electrolytic 100 µF 10V
CN11	YW530150510	5-pin Connector	C11.12	EU1FC1E332L	Electrolytic 3300 µF 25V
E1.2	YWME1P866	Terminal	C13.14	MCU01E104KBN	Ceramic 0.1 µF
			C15	F1JC1E3331L	Electrolytic 330 µF 25V
			C16	EKOH16818K	Ceramic 680 pF
			C17.18	EU1FC1482ZL	Electrolytic 8200 µF 10V
			C20	MCU01E104KBN	Ceramic 0.1 µF
			C21	EU1FC1471	Electrolytic 470 µF 10V
			C22.24	EU1FC1482ZL	Electrolytic 8200 µF 10V
			C25	EU1FC1471	Electrolytic 470 µF 10V
			C26	F1BZE1520002	Ceramic 1500 pF
POWER BOARD			C27	FCXK01011K1KP	Ceramic 100 µF
PCB# (RTL)	J860KIC24A	Printed Circuit Board Assy	C31	F1JC11050002	1 µF
IC1	MP10Z275Y	IC	L1.2	J0H2E200001	Line Filter
D1	WY1A764315	IC	L6.7	G0Z700000349	33 µH
IC3	CD04E29H0002	IC	T1	G4D300000026	Power Transformer
Q1.2	YW5C32F2	Photocoupler	F1	K02C12B0003	Current Fuse 3.15 A 250V
D1	YW0D35860	Diode	F2	K5092E000602	Current Fuse 5 A 250V
R2	B9M4Z2200002	Diode	SW1	YW5SD34F	Push Switch
D3	YWERB7310	Diode	CN1	YW6P3910W	2-pin Connector
D4	YW5C2012	Diode	CN2	YWL04AT	4-pin Connector
D5	YW5F10LCS8U	Diode	E1.4	YW53014 0210	2-pin Connector
			E5-7	K3C21B800004	Fuse Holder
D8.9	YW5F10S5C6	Diode	E8	YWME1P866	Terminal
DB1	DAP700P 146	Diode	E9	KCZ00000151	Holder for IC3, IC4
Q1.1	ERC010041	ZMS			
R1	ERC122GM105	Solid	E10	JH0500110A	Jumper Wire
R2.3	ERJ14Y.813	Metal	E13.14	YFCZD0000049	4-pin Connector
			E15	B1Z7Z000015	Insulation Cap for C10
R4	ERJ14Y0R00H	Metal	E16	YW800522	Fuse Cover for IC1
R6	ERG3S3181P	Metal	M83	YWAC-256	Cool Sheet (x2)
R7	ERG3E3140TV	Metal	M84	P32124C35PB	Heat Sink (x2)
R8-10	YF21614J33T	Metal	M85	V7D1A140E2	Heat Sink
R11	ERG3S333T	Metal			
R13	D1B056P00001	Metal			
R14	YWR122P332D	Metal			
R15	YWR122P391D	Metal			
R19	ERJ14Y.1150	Metal			
R20.21	ERJAGEYJ2TV	Metal			
R22	ERJAGEYJ194V	Metal			
R23	YF21614J07T	Metal			
R24	ERJAGEYJ332V	Metal			
R25	ERJAGEYJ382V	Metal			
R27	ERJAGEYJ362V	Metal			
R29	ERJAGEYJ192V	Metal			
R32	VDS4S1000101	Variable Resistor			
C1	ECQ04A56M3T	Plastic			
C2.3	F1BZE1520002	Ceramic			
C4	ECQ04A56M3T	Plastic			
			SCS-IDE BOARD		
			Note: SCS-IDE Board Assy (PCB1) is supplied as Assy only.		
PCB1 (RTL)	N5DZ0000002	Printed Circuit Board Assy			

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
MOTION DETECTOR BOARD			R116	WV0816P122V	Metal 1K ohms 116W
PCBR (RTL)	JH0B5K72TA	Printed Circuit Board Assy	R117	ERJ6YF322V	Metal 2.7K ohms 116W
C101	C0FBA0000003	IC	R118	ERJ6YF335V	Metal 15K ohms 116W
IC102-103	C0BA5000001	IC	R119	ERJ6YF330V	Metal 10K ohms 116W
IC150	YWNJM226V1T1	IC	R120	ERJ6YF360V	Metal 56K ohms 116W
IC151	YVW47040ADTE	IC	R122	ERJ6YF322V	Metal 2.2K ohms 116W
IC152-153	C0BA2000005	IC	R123	WV0816P122V	Metal 1K ohms 116W
IC160	C0BA2001058	IC	R124	ERJ6YF310V	Metal 10K ohms 116W
IC201	C0FBA0000003	IC	R125	ERJ6YF354V	Metal 150K ohms 116W
IC202-203	C0BA5000001	IC	R126	ERJ6YF310ZV	Metal 1K ohms 116W
IC602-604	C0BA2000529	IC	R127-128	ERJ6YF310V	Metal 100 ohms 116W
IC609-610	C0BA0000413	IC	R201-203	ERJ6YF080	Metal 0 ohm 116W
IC613	C1BZ0001228	IC	R204	ERJ6YF310V	Metal 470 ohms 116W
IC614	C1C80A000014	IC	R605	ERJ6YF316V	Metal 100 ohms 116W
IC615	C1CB8K000002	IC	R206	ERJ6YF312V	Metal 4.7K ohms 116W
IC617	C0BA2000529	IC	R207	FR1CF3F333V	Metal 330 ohms 116W
IC619	C0B0E3F00001	IC	R208	ERJ6YF310ZV	Metal 1K ohms 116W
Q101	2SD1819AHL	Transistor	R209	ERJ6YF080	Metal 0 ohm 116W
Q102	2SB1218AHL	Transistor	R211	ERJ6YF332V	Metal 3.3K ohms 116W
Q103-105	2SD1819AHL	Transistor	R212	ERJ6YF312V	Metal 4.7K ohms 116W
Q106	2SB1218AHL	Transistor	R213	ERJ6YF310ZV	Metal 1K ohms 116W
Q107-201	2SD1819AHL	Transistor	R214	ERJ6YF310V	Metal 10K ohms 116W
Q202	2SD1218AHL	Transistor	R215	ERJ6YF312V	Metal 3.3K ohms 116W
Q203-205	2SD1819AHL	Transistor	R216	WV0816P122V	Metal 1K ohms 116W
Q206	2SB1218AHL	Transistor	R217	ERJ6YF322V	Metal 2.7K ohms 116W
Q207	2SD1819AHL	Transistor	R218	WV0816P122V	Metal 1K ohms 116W
Q601	B1CFBC00007	FET	R219	ERJ6YF335V	Metal 15K ohms 116W
Q602	B1CFBC00001	FET	R220	ERJ6YF310ZV	Metal 1K ohms 116W
Q603	B1CFBC00000	FET	R220	ERJ6YF356V	Metal 560 ohms 116W
Q604	B1CFBC00007	Transistor	R222	ERJ6YF322V	Metal 2.2K ohms 116W
Q605	B1CFBC00001	FET	R223	WV0816P122V	Metal 1K ohms 116W
Q606	B1CFDC00003	FET	R224	ERJ6YF310V	Metal 100 ohms 116W
Q613-620	2SD1819AHL	Transistor	R225	ERJ6YF310V	Metal 150K ohms 116W
D601	LN1361CTR	Diode	R226	ERJ6YF310ZV	Metal 3.3K ohms 116W
D602-603	MA2327ZE0L	Diode	R227-228	ERJ6YF310V	Metal 100 ohms 116W
D604	LN1361CTR	LED	R601	ERJ6YF333V	Metal 330 ohms 116W
D605	MA2327ZE0L	Diode	R602	ERJ6YF332V	Metal 3.3K ohms 116W
D61-619	LN1261CTR	LED	R603-605	ERJ6YF310ZV	Metal 1K ohms 116W
R606	MA2327ZE0L	Diode	R606	ERJ6YF310V	Metal 3.3K ohms 116W
R101-103	ERJ6YF080	Metal 4.7K ohms 116W	R607-608	ERJ6YF310V	Metal 10K ohms 116W
R104	ERJ6YF310V	Metal 0 ohm 116W	R609	ERJ6YF312V	Metal 470 ohms 116W
R105	ERJ6YF310V	Metal 100 ohms 116W	R610	ERJ6YF310V	Metal 100 ohms 116W
R106	ERJ6YF312V	Metal 4.7K ohms 116W	R611	ERJ6YF310V	Metal 330 ohms 116W
R107	ERJ6YF333V	Metal 330 ohms 116W	R612	ERJ6YF333V	Metal 3.3K ohms 116W
R108	ERJ6YF310ZV	Metal 1K ohms 116W	R613-615	ERJ6YF310V	Metal 1K ohms 116W
R109	ERJ6YF080	Metal 0 ohm 116W	R616	ERJ6YF332V	Metal 3.3K ohms 116W
R111	ERJ6YF312V	Metal 3.3K ohms 116W	R617-618	FR1CF3F333V	Metal 10K ohms 116W
R112	ERJ6YF312V	Metal 1K ohms 116W	R619	ERJ6YF312V	Metal 470 ohms 116W
R113	ERJ6YF310V	Metal 1K ohms 116W	R620	ERJ6YF310V	Metal 100 ohms 116W
R114	ERJ6YF312V	Metal 10K ohms 116W	R621	ERJ6YF310V	Metal 1M ohms 116W
R115	ERJ6YF312V	Metal 1.3K ohms 116W	R623	ERJ6YF080	Metal 0 ohm 116W
			R647	ERJ6YF322V	Metal 2.2K ohms 116W

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
R670	ERJGEYH3V	Metal 10K ohms 176W	C114	FHHH220404	Ceramic 220 pf
R671	ERJGEYH3V	Metal 0 ohm 176W	C115	FHHH212404	Ceramic 12 pf
R672-673	ERJGEYH3V	Metal 10K ohms 176W	C116	FHHH226004	Ceramic 22 pf
R675	ERJGEYH3V	Metal 10K ohms 176W	C117	FHHH331404	Ceramic 330 pf
R676	ERJGEY22W	Metal 22 ohms 176W	C118	FHHH366404	Ceramic 1 pf
R681-682	ERJGEYH3V	Metal 10K ohms 176W	C150	MCUV104ZV	Ceramic 10 pf
R683	ERJGEYH3V	Metal 0 ohm 176W	C151-152	FHHH104ZV	Ceramic 1 pf
R684-689	ERJGEYH3V	Metal 10K ohms 176W	C153	EEVH0221P	Electrolytic 220 pf 6.3V
R690-692	ERJGEY000	Metal 0 ohm 176W	C154	MCUV104ZV	Ceramic 10 pf
R693	ERJGEYH3V	Metal 10K ohms 176W	C159	FHHH102404	Ceramic 1000 pf
R702	ERJGEYH3V	Metal 10K ohms 176W	C202	MCUV104ZV	Ceramic 10 pf
R703	ERJGEY000	Metal 0 ohm 176W	C203	FHHH214204	Ceramic 220 pf
R704	ERJGEYH3V	Metal 10K ohms 176W	C204-206	FHHH104ZV	Ceramic 10 pf
R705-712	ERJGEYH3V	Metal 0 ohm 176W	C207	CEVH0101P	Electrolytic 100 pf 6.3V
R713	ERJGEYH3V	Metal 100 ohms 176W	C209-210	FHHD105A01	Ceramic 1 pf
R734	ERJGEYH3V	Metal 10K ohms 176W	C212	FHHH000002	Ceramic 7 pf
R735	ERJGEYH3V	Metal 470 ohms 176W	C213	FHHH366404	Ceramic 36 pf
R736-737	ERJGEYH3V	Metal 10K ohms 176W	C214	FHHH220404	Ceramic 22 pf
R738	ERJGEY000	Metal 0 ohm 176W	C215	FHHH212404	Ceramic 12 pf
R739-746	ERJGEYH3V	Metal 10K ohms 176W	C216	FHHH220404	Ceramic 22 pf
R727-730	ERJGEY000	Metal 0 ohm 176W	C217	FHHH331404	Ceramic 330 pf
R731	ERJGEYH3V	Metal 10K ohms 176W	C218	+HHA1040404	Ceramic 1 pf
R732-735	ERJGEY39V	Metal 390 ohms 176W	C254-255	MCUV104ZV	Ceramic 10 pf
R736-738	ERJGEYH3V	Metal 10K ohms 176W	C256	FHHH022404	Ceramic 22 pf
R739-742	ERJGEY39V	Metal 390 ohms 176W	C596	EEVH0221P	Electrolytic 220 pf 6.3V
R743-746	ERJGEYH3V	Metal 10K ohms 176W	C601	FHHH104A01	Ceramic 0.1 pf
R747	ERJGEYH3V	Metal 10K ohms 176W	C602	FHHH104A01	Ceramic 0.1 pf
R749-757	ERJGEY000	Metal 0 ohm 176W	C603	FHHH100617	Ceramic 10 pf
R758	ERJGEYH3V	Metal 10K ohms 176W	C604	FHHH180404	Ceramic 18 pf
R759	YWMR081P212	Metal 120 ohms 176W	C605-606	FHHH331404	Ceramic 330 pf
R760	ERJGEY000	Metal 0 ohm 176W	C607-608	MCUV104ZV	Ceramic 0.1 pf
R761	YWMR081P212	Metal 120 ohms 176W	C609	FHHH104A01	Ceramic 0.1 pf
R762-763	YWMR081P212	Metal 120 ohms 176W	C610-611	FHHH104A01	Ceramic 0.1 pf
VR101	EVMD35W3681	Semifixed Resistor 18 khms	C611	FHHH100617	Ceramic 10 pf
VR102	EVMD3A0852	Semifixed Resistor	C612	FHHH331404	Ceramic 330 pf
VR201	EVMD35W3681	Semifixed Resistor 18 khms	C613	FHHH180404	Ceramic 18 pf
VR202	EVMD3A0852	Semifixed Resistor	C614-615	FHHH331404	Ceramic 330 pf
Z601-602	WMNMR4E1Z20	Block Resistor 22 ohms	C616-617	MCUV104ZV	Ceramic 0.1 pf
Z603-607	WMNMR4E103	Block Resistor 10K ohms	C618	FHHH102403	Ceramic 10 pf
Z608	WMNMR4E1Z20	Block Resistor 22 ohms	C654	MCUV104ZV	Ceramic 0.1 pf
Z609	WMNMR4E103	Block Resistor 10K ohms	C655-656	FHHH331404	Ceramic 330 pf
Z610	WMNMR4E1Z20	Block Resistor 22 ohms	C657	FHHH206004	Ceramic 12 pf
Z611	WMNMR4E103	Block Resistor 10K ohms	C659	FHHH220404	Ceramic 22 pf
Z612	WMNMR4E1Z20	Block Resistor 22 ohms	C660-672	MCUV104ZV	Ceramic 0.1 pf
Z613	WMNMR4E103	Block Resistor 10K ohms	C673-675	ECSTC336R	Tantalum 33 pf 16V
Z614	WMNMR4E1Z20	Block Resistor 22 ohms	C676	FHHH331404	Ceramic 330 pf
Z615	WMNMR4E103	Block Resistor 10K ohms	C677	ECSTC3336R	Tantalum 33 pf 16V
Z616-623	WMNMR4E1Z20	Ceramic 22 pf	C678-679	MCUV104ZV	Ceramic 0.1 pf
C102	MCUV104ZV	Ceramic 0.1 pf	C680	ECSTC3336R	Tantalum 33 pf 16V
C103	FHHH221404	Ceramic 220 pf	C682	MCUV104ZV	Ceramic 0.1 pf
C104-106	MCUV104ZV	Ceramic 0.1 pf	C699	ECSTC3336R	Tantalum 33 pf 16V
C107	CEVH0101P	Electrolytic 100 pf 6.3V	L101	ELF0101F	Coil 100 pf
C108-110	FHHD105A01	Ceramic 1 pf	L102	ELF0201F	Coil 10 pf
C111	FHHH000002	Ceramic 7 pf	L150	G1C82R-00002	Coil 8.2 pf
C113	FHHH366404	Ceramic 36 pf	L201	ELF0101F	Coil 100 pf

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
L202	ELJFC020 IF	Call	82 µH		
L502	GHCB82 J00002	Call	8.2 µH		
L601-006	ELJPA1000P	Call	10 µH		
L607-608	EC4E J011E	Call	1.92 µH		
L601	HWJZ7000003	Crystal Oscillator			
SW601	K0D222A00019	Slide Switch			
CN101-601	KWB52400003	52-pin Connector			
E601-603	K4CD01000002	Terminal			
TP101-104	YWRC12125TPV	Test pin			
TP201-601	YWRC12125TPV	Test pin			
TP602-605	YWRC12125TPV	Test pin			
			ACCESSORY PARTS / PACKAGING PARTS		
E100	△	YWKP610575R	AC Power Cord		
E101	△	YWKP6109CE25	AC Power Cord		
M27		VTEA104104	Hard Disk Flang Screw (x4)		
M28		V1BA6050A4	Sleeve (x4)		
M29		V2PA1260A4	Absorber (x4)		
M46		V4JA1150A4	Earth Lug		
M90		X5B4-101N	Screw for Rack Mounting Bracket (x4)		
M91	△	VR0AS550AM	Operating Instructions		
M92	△	VR0AS5506AM	Operating Instructions		
M93		PE20X40C05B	Polyethylene Bag		
M94		YWT10X16C03	Polyethylene Bag (x3)		
M95		PE20X35C05B	Polyethylene Bag		
M96		YVW/SPB0005A4	Rack Mounting Bracket (x2)		
M97		PE30X70C10	Polyethylene Bag		
M98		V9CA4283AM	Packaging Assy		